

Tamworth Borough Level 1 Strategic Flood Risk Assessment

Final Report

June 2025

Prepared for:
Tamworth Borough Council

www.jbaconsulting.com

Document Status

Issue date	27 June 2025
Issued to	Richard Powell
BIM reference	NPW-JBA-XX-XX-RP-Z-0001
Revision	A1-C01

Prepared by	Dylan Nattrass BSc Technical Assistant Grace Sheppard BSc Technical Assistant Elsa Holm Technical Assistant
-------------	--

Reviewed by	Joanne Chillingworth BSc MSc MCIWEM C.WEM Associate Director
-------------	---

Authorised by	Joanne Chillingworth BSc MSc MCIWEM C.WEM Associate Director
---------------	---

Carbon Footprint

The format of this report is optimised for reading digitally in pdf format. Paper consumption produces substantial carbon emissions and other environmental impacts through the extraction, production, and transportation of paper. Printing also generates emissions and impacts from the manufacture of printers and inks and from the energy used to power a printer. Please consider the environment before printing.

Contract

JBA Project Manager	Rachel Flood
Address	1 Broughton Park, Old Lane North, Broughton, Skipton, North Yorkshire, BD23 3FD
JBA Project Code	2024s1074

This report describes work commissioned by Tamworth Borough Council by an instruction dated 10th July 2024. The Client's representative for the contract was Richard Powell of Tamworth Borough Council. Rachel Flood, Dylan Nattrass, and Grace Sheppard of JBA Consulting carried out this work.

Purpose and Disclaimer

Jeremy Benn Associates Limited ("JBA") has prepared this Report for the sole use of Tamworth Borough Council and its appointed agents in accordance with the Agreement under which our services were performed.

JBA has no liability for any use that is made of this Report except to Tamworth Borough Council for the purposes for which it was originally commissioned and prepared.

No other warranty, expressed or implied, is made as to the professional advice included in this Report or any other services provided by JBA. This Report cannot be relied upon by any other party without the prior and express written agreement of JBA.

Acknowledgements

We would like to acknowledge the assistance of Tamworth Borough Council, the Environment Agency, Staffordshire County Council, Severn Trent Water, and planners at the neighbouring authorities.

Copyright

© Jeremy Benn Associates Limited 2025

Contents

Executive Summary	xiii
1 Introduction	1
1.1 Purpose of a Strategic Flood Risk Assessment (SFRA)	1
1.2 Levels of SFRA	1
1.3 Study area	2
1.4 Consultation	2
1.5 Structure of this report	5
2 Flood risk policy and strategy	8
2.1 Roles and responsibilities for Flood Risk Management across the borough	8
2.2 Relevant legislation	9
2.3 Key national, regional, and local policy documents and strategies	10
3 Planning policy for flood risk management	18
3.1 National Planning Policy Framework and Guidance	18
3.2 The sequential test	18
3.3 The Exception Test	21
3.4 Applying the sequential test and exception test to individual planning applications	23
4 Understanding flood risk across the borough	26
4.1 Defining flood risk	26
4.2 Historical flooding	27
4.3 Topography, geology, and soils	30
4.4 Fluvial flood risk	34
4.5 Surface water flooding	35
4.6 Sewer flooding	36
4.7 Groundwater flooding	37
4.8 Flooding from reservoirs	38
4.9 Flooding from canals	43
4.10 Flood alerts and flood warnings	43
4.11 Summary of flood risk in the borough	44
5 Impact of Climate Change	46

5.1	Revised climate change guidance	46
5.2	Relevant allowances for the study area	47
5.3	Representing climate change in the Level 1 SFRA	48
6	Flood alleviation schemes and assets	53
6.1	Asset management	53
6.2	Standards of Protection	53
6.3	Maintenance	54
6.4	Major flood risk management assets in the borough	55
6.5	Existing and future flood alleviation schemes	58
6.6	Actual and residual flood risk	58
7	Cumulative impact of development and strategic solutions	61
7.1	Introduction	61
7.2	Methodology	61
7.3	Catchment Level Assessment	66
7.4	Natural Flood Management (NFM)	71
8	Flood risk management requirements for developers	73
8.1	Principles for new development	73
8.2	Requirements for site-specific Flood Risk Assessments	77
8.3	Resistance and resilience measures	81
8.4	Reducing flood risk from other sources	82
8.5	Emergency planning	84
9	Surface water management and SuDS	86
9.1	Roles of the Lead Local Flood Authority and Local Planning Authority in surface water management	86
9.2	Sustainable Drainage Systems (SuDS)	86
9.3	Sources of SuDS guidance	87
9.4	Other surface water considerations	88
10	Recommendations	90
10.1	Borough-wide recommendations	90
10.2	Recommendations from the CIA	93
10.3	Requirements for a Level 2 SFRA	95
10.4	SFRA report recommendations	95

Appendices A-1

A	GeoPDF Mapping and User Guide	A-1
B	Data Sources used in this SFRA	B-2
C	SFRA User Guide: Sequential test methodology	C-3
D	Summary of flood risk across the borough	D-4

List of Figures

Figure 1-1: Tamworth borough and its neighbouring authorities.	3
Figure 1-2: Main rivers and other watercourses across the borough.	4
Figure 3-1: The Sequential Test.	19
Figure 3-2: Application of the sequential test for plan preparation.	20
Figure 3-3: Application of the exception test to plan preparation.	22
Figure 4-1: Conceptual model depicting how risk can be defined.	26
Figure 4-2: Locations of historic flooding from the EA's Historic Flood Map.	29
Figure 4-3: EA 1m LiDAR data showing the topography across the borough.	32
Figure 4-4: Aquifer designations based on bedrock geology across the borough.	33
Figure 4-5: Reservoirs located in the borough with flood extents that impact the borough.	42
Figure 4-6 Sub-Areas used to divide Tamworth Borough and summarise flood risk	45
Figure 7-1 WFD Catchments across Tamworth Borough.	64
Figure 9-1: SuDS Management Train.	87

List of Tables

Table 1-1: Sets out the contents of the report and how to use each section.	5
Table 2-1: Roles and responsibilities for RMAs.	8
Table 2-2: National, regional, and local flood risk policy and strategy documents.	11
Table 4-1: Properties with sewer flooding incidences recorded by Severn Trent Water (June 1997 and August 2024).	36
Table 4-2: Reservoirs located outside the borough but where the flood extents impact the borough.	40
Table 5-1: Peak river flow allowances for the Tame, Anker and Mease Management Catchment.	47
Table 5-2: Peak rainfall intensity allowances for small and urban catchments for the Tame, Anker and Mease Management Catchment.	48
Table 6-1: Flood risk asset maintenance responsibilities.	54
Table 6-2: Grading system used by the EA to assess flood defence condition.	55
Table 6-3: Locations shown in the EA 'AIMS' data set.	56
Table 7-1 Datasets used in the BROADSCALE CIA	62
Table 7-2 Assumptions made in CIA methodology	65

Abbreviations

ACDP	Area with Critical Drainage Problems
AEP	Annual Exceedance Probability
AStGWF	Areas Susceptible to Groundwater Flooding
CC	Climate Change
CDA	Critical Drainage Area
CFMP	Catchment Flood Management Plan
CIRIA	Construction Industry Research and Information Association
Defra	Department for Environment, Food and Rural Affairs
EA	Environment Agency
EU	European Union
FAA	Flood Alert Area
FCERM	Flood and Coastal Erosion Risk Management
FFL	Finished Floor Level
FRA	Flood Risk Assessment
FRMP	Flood Risk Management Plan
FWA	Flood Warning Area
FWMA	Flood and Water Management Act
FWS	Flood Warning System
GSPZ	Groundwater Source Protection Zone
IDB	Internal Drainage Board
JBA	Jeremy Benn Associates
LFRMS	Local Flood Risk Management Strategy
LiDAR	Light Detection and Ranging
LLFA	Lead Local Flood Authority
LPA	Local Planning Authority
LPU	Local Plan Update
mAOD	metres Above Ordnance Datum
NFM	Natural Flood Management
NPPF	National Planning Policy Framework
NRD	National Receptor Database
NVZs	Nitrate Vulnerable Zones
PFRA	Preliminary Flood Risk Assessment

PPG	Planning Practice Guidance
RBD	River Basin District
RBMP	River Basin Management Plan
RFCC	Regional Flood and Coastal Committee
RMAs	Risk Management Authorities
RoFSW	Risk of Flooding from Surface Water
SCC	Staffordshire County Council
SFRA	Strategic Flood Risk Assessment
SMP	Shoreline Management Plan
SoP	Standard of Protection
SSSI	Site of Special Scientific Interest
SuDS	Sustainable Drainage Systems
SWMP	Surface Water Management Plan
TBC	Tamworth Borough Council
WFD	Water Framework Directive

Definitions

1D model: one-dimensional hydraulic model.

2D model: two-dimensional hydraulic model.

Annual Exceedance Probability: the probability (expressed as a percentage) of a flood event occurring in any given year.

Brownfield: previously developed parcel of land.

Catchment Flood Management Plan: a high-level planning strategy through which the EA works with their key decision makers within a river catchment to identify and agree policies to secure the long-term sustainable management of flood risk.

Climate Change: long term variations in global temperature and weather patterns caused by natural and human actions.

Cumecs: the cumec is a measure of flow rate. One cumec is shorthand for cubic metre per second (m^3/s).

Design flood: This is a flood event of a given annual flood probability, which is generally taken as: fluvial (river) flooding likely to occur with a 1% annual probability (a 1 in 100 chance each year), or surface water flooding likely to occur with a 1% annual probability (a 1 in 100 change each year), plus an appropriate allowance for climate change, against which the suitability of a proposed development is assessed and mitigation measures, if any, are designed.

Exception test: Set out in the NPPF, the exception test is a method used to demonstrate that flood risk to people and property will be managed appropriately, where alternative sites at a lower flood risk are not available. The exception test is applied following the sequential test. As set out in Paragraph 170 of the NPPF (December 2023), the exception test should demonstrate that: development that has to be in a flood risk area will provide wider benefits to the community that outweigh flood risk; and the development will be safe for its lifetime taking account of the vulnerability of its users, without increasing flood risk elsewhere, and, where possible, will reduce flood risk overall.

Flood defence: Infrastructure used to protect an area against floods such as floodwalls and embankments; they are designed to a specific standard of protection (design standard).

Flood Map for Planning: The EA Flood Map for Planning (Rivers and Sea) is an online mapping portal which shows the Flood Zones in England. The Flood Zones refer to the probability of river and sea flooding, ignoring the presence of defences and do not account for the possible impacts of climate change.

Flood Risk Assessment: a site-specific assessment of all forms of flood risk to the site and the impact of development of the site to flood risk in the area.

Fluvial Flooding: Flooding resulting from water levels exceeding the bank level of a river (main river or ordinary watercourse).

Green Infrastructure: a network of multi-functional green and blue spaces and other natural features, urban and rural, which is capable of delivering a wide range of environmental, economic, health and wellbeing benefits for nature, climate, local and wider communities and prosperity (NPPF, December 2023).

Greenfield: undeveloped parcel of land.

Lead Local Flood Authority: the unitary authority for the area or if there is no unitary authority, the county council for the area.

Local Flood Risk Management Strategy: the Lead Local Flood Authority (LLFA) are responsible for developing, maintaining, applying, and monitoring a Local Flood Risk Management Strategy which sets out objectives for managing local flooding and is used by the LLFA to co-ordinate flood risk management on a day-to-day basis.

Main river: a watercourse shown as such on the statutory main river map held by the Environment Agency. They are usually the larger rivers and streams. The Environment Agency has permissive powers (not duties) to carry out maintenance and improvement works on main rivers).

Major development: defined in the National Planning Policy Framework (NPPF) as a housing development where 10 or more homes will be provided, or the site has an area of 0.5 hectares or more, or as a non-residential development with additional floorspace of 1,000m² or more, or a site of 1 hectare or more, or as otherwise provided in the Town and Country Planning (Development Management Procedure) (England) Order 2015 available [here](#).

Ordinary watercourse: any river, stream, ditch, drain, cut, dyke, sluice, sewer (other than a public sewer) and passage through which water flows but which does not form part of a main river. The local authority or internal drainage board has permissive powers (not duties) on ordinary watercourses.

Permissive Powers: authorities have the power to undertake flood risk management activities, but not a duty to do so. This will depend on priorities in flood risk management.

Pitt Review: Comprehensive independent review of the 2007 summer floods by Sir Michael Pitt, which provided recommendations to improve flood risk management in England.

Pluvial flooding: see surface water flooding.

Resilience measures: Measures designed to reduce the impact of water that enters property and businesses; could include measures such as raising electrical appliances.

Resistance measures: Measures designed to keep flood water out of properties and businesses; could include flood guards for example.

Return period: Is an estimate of the interval of time between events of a certain intensity or size, in this instance it refers to flood events. It is a statistical measurement denoting the average recurrence interval over an extended period of time.

Riparian owner: A riparian landowner, in a water context, owns land or property, next to a river, stream or ditch.

Risk Management Authority: the Environment Agency; a lead local flood authority; a district council in an area where there is no unitary authority; an internal drainage board; a water company and a highway authority.

Risk: In flood risk management, risk is defined as a product of the probability or likelihood of a flood occurring, and the consequence of the flood.

Sequential test: Set out in the NPPF, the sequential test is a method used to steer new development to areas with the lowest probability of flooding. The sequential test is a risk-based approach, taking into account all sources of flood risk and climate change.

Sewer flooding: Flooding caused by a blockage or overflowing in a sewer or urban drainage system.

Stakeholder: A person or organisation affected by the problem or solution or interested in the problem or solution. They can be individuals or organisations, includes the public and communities.

Standard of Protection: Defences are provided to reduce the risk of flooding from a river and within the flood and defence field standards are usually described in terms of a flood event return period. For example, a flood embankment could be described as providing a 1% AEP (1 in 100 year) standard of protection.

Surface water flooding: Flooding as a result of surface water runoff as a result of high intensity rainfall when water is ponding or flowing over the ground surface before it enters the underground drainage network or watercourse or cannot enter it because the network is full to capacity.

Surface Water Management Plan: SWMPs are non-statutory plans which are used to assess existing surface water problems in an area, identify options to manage the level of surface water risk, and inform investment decisions and planning decisions for new development. They also provide an evidence base for the development of local flood risk management strategies.

Sustainable Drainage Systems: SuDS are methods of management practices and control structures that are designed to drain surface water in a more sustainable manner than some conventional techniques, such as grates, gullies, and channels.

Water Framework Directive: Under the WFD, all waterbodies have a target to achieve Good Ecological Status (GES) or Good Ecological Potential (GEP) by a set deadline. River Basin Management Plans (RBMPs) set out the ecological objectives for each water body and give deadlines by when objectives need to be met.

Windfall site: a site which becomes available for development unexpectedly and therefore not included as allocated land in a planning authority's Local Plan.

Executive Summary

This report provides a comprehensive and robust evidence base on flood risk issues to support the review and update of the planning policies for Tamworth Borough. The review process is known as the Local Plan Update (LPU). This report uses the best available information, including input from key stakeholders. The SFRA applies the latest national planning policy and guidance, including:

- [National Planning Policy Framework \(NPPF\) \(gov.uk\)](#), revised in July 2021 and further updated in December 2023.
- [Planning Practice Guidance \(PPG\): Flood risk and coastal change \(gov.uk\)](#) updated in August 2022.
- Updates to the [EA climate change guidance \(gov.uk\)](#) in July 2021 and May 2022.

Introduction

To support the review and LPU for Tamworth Borough Council (referred to hereafter as the Council), the key objectives of the assessment are:

- To collate and analyse the latest available information and data for current and future (i.e., climate change) flood risk from all sources, and how these risks may be mitigated against.
- To inform decisions in the emerging LPU, including informing the sustainability appraisal, the selection of development sites, and planning policies.
- To provide evidence to support the application of the sequential test for the allocation of new development sites, to support the Council in the preparation of the LPU.
- To provide a comprehensive set of maps presenting flood risk from all sources that can be used as evidence base for use in the LPU.
- To help decide when a Flood Risk Assessment (FRA) will be required for individual planning applications.
- To provide advice for applicants carrying out site-specific Flood Risk Assessments (FRAs), including those at risk from sources other than river flooding, or at risk of flooding in the future due to climate change, and outline specific measures or objectives that are required to manage flood risk.
- To provide the basis for applying the sequential test on planning applications, including by identifying sources of flooding other than those in 'Flood Zones' and those at risk of flooding in the future.
- To identify opportunities to reduce the causes and impacts of flooding and gather information on the land that is likely to be required for flood risk management structures.

Summary of the borough and flood risk

This SFRA covers the borough of Tamworth, a small borough covering the Tamworth urban area.

Flood risk from all sources has been assessed in this SFRA. Parts of the borough are shown to be at risk of flooding from the following sources: fluvial, surface water, groundwater, sewers, and reservoir inundation. This study has shown that the most significant sources of flood risk across the borough are fluvial and surface water. The points below summarise the findings:

Fluvial: The borough lies within the Tame, Anker, and Mease Management Catchment. The River Anker flows from east to west through the northeast of the borough, to its confluence with the River Tame in Tamworth. The River Tame flows from south to north through the west of the borough. Other smaller tributaries of these main rivers in the borough include Kettle Brook and Fazeley Brook.

The River Tame and River Anker are the primary sources of fluvial flood risk within the borough. Areas including Coton Farm, Lichfield Road Industrial Estate, Ventura Retail Park and residential estates south of the A5 by the border near Fazeley in the west of the Borough are within fluvial Flood Zones associated with the River Tame. Fluvial flood extents associated with the River Anker affect some areas in Amington and Bolehall in the northeast of the borough. The Kettle Brook also poses risk of fluvial flooding to properties in Wilnecote and Kettlebrook.

Fluvial flood risk is discussed in Section 4.4 and Appendix D and the flood extents are shown in the GeoPDFs in Appendix A.

Surface Water: The EA Risk of Flooding from Surface Water mapping (RoFSW) shows that surface water flow routes largely flow from higher ground into the lower topography of watercourse floodplains in the Borough, including the River Anker, the River Tame, and Kettle Brook. In particular, there are prominent overland flow paths established along a significant portion of the River Anker floodplain in the northeast, flowing west. While this affects primarily rural land, there are also considerable flow paths and isolated areas of ponding in urban areas across the entire borough. This includes properties and infrastructure in Dosthill (predominantly from Hockley to Hedging Lane), Two Gates and Belgrave in the south, Stonydelph (converging south-west at the nature reserve), Glascote and Amington in the east (converging north around Brindley Drive and the railway embankment), and Leyfields (including impounding along the railway embankment) and around the County Drive estate north of Fazeley in the west. Settlements located below higher elevation areas are particularly at risk. Main transport links are also at risk of surface water flooding, including the A5 and both the Trent Valley and Derby-to-Birmingham railway lines.

Surface water flood risk is discussed in Section 4.5 and Appendix D and the flood extents are shown in the GeoPDFs in Appendix A.

Climate Change: Areas at risk of flooding today are likely to become at increased risk in the future and the frequency of flooding will also increase in such areas, due to climate

change. Flood extents will increase; in some locations this may be minimal, but flood depth, velocity and hazard may have more of an impact due to climate change. This SFRA provides an assessment of the impacts of climate change on fluvial and surface water flood risk.

The approach to climate change is discussed in Section 5 and the flood extents are also shown in the GeoPDFs in Appendix A.

It is recommended that the Council work with other Risk Management Authorities (RMAs) to review the long-term sustainability of existing and new development when developing climate change plans and strategies for the borough.

Sewer: Severn Trent Water provide water services and sewerage services across the borough. Severn Trent Water have also provided details of historic sewer flooding across the borough. Postcodes identified with a high number of previous sewer flooding events in several areas include: Two Gates, Dosthill, Belgrave, Glascote Heath, Bolehall, Amington, Stonydelph, Hockley, Fazeley, Lichfield Road, Coton Farm, and Leyfields. *Sewer flood risk is discussed in Section 4.6.*

Groundwater: The Areas Susceptible to Groundwater Flooding map shows that, overall, a large part of the northwest has a greater than 75% susceptibility to groundwater flooding, as well as an area in the northeast where an unnamed tributary leads to Mallard Halt. There are areas with greater than 50% susceptibility in Coton Farm, Dosthill, between the Tamworth Railway Station and Amington, and the rural lands north of Anker Valley Sports Complex. The JBA Groundwater Emergence Map reflects this, with significant parts of the northwest and northeast having groundwater levels that are at or very near (within 0.025m of) the ground surface. In the northwest, this includes Coton Farm, Lichfield Road Industrial Estate, and the north of Fazeley. In the northeast, this encompasses the rural areas surrounding the River Anker. There are further regions with groundwater emergence levels either at or very near (within 0.025m of) the ground surface by the River Tame north of Dosthill, and between Stonydelph and Wilnecote. There is no national groundwater flood dataset to inform the areas at risk from groundwater flooding; however, emergence mapping when considered in conjunction with topography and surface water flow paths can indicate areas where groundwater is likely to emerge, and the flow paths it may take once above the ground.

Groundwater flood risk is discussed in Section 4.7 and Appendix D, and the AStGWF map and JBA emergence map are shown in the GeoPDFs in Appendix A.

Reservoirs: There are 16 reservoirs located outside the study area where the 'wet day' or 'dry day' scenario extents encroach into the borough. Flood extents follow the watercourses of the River Tame and Anker, with potential risk of flooding affecting significant areas of the northwest and northeast, as well as mainly rural land by the southwest boundary. The level and standard of inspection and maintenance required under the Reservoirs Act means that the risk of flooding from reservoirs is relatively low. However, there is a residual risk of a reservoir breach, and this risk should be considered in any site-specific FRAs (where relevant) in accordance with the updated PPG: Flood risk and coastal change.

Reservoir flood risk is discussed in Section 4.8 and Appendix D. The 'Dry Day' and 'Wet Day' flood extents are shown in the GeoPDFs in Appendix A.

Defences

The EA Asset Information Management System (AIMS) dataset provides information on flood defence assets across the borough. The only formal flood defences are located in the northwest of the borough along the River Tame, consisting of a combination of floodbanks, floodwalls, and engineered high ground at various stages along the watercourse. *Further information on defences across the borough is available in Section 6.4 and shown in the GeoPDFs in Appendix A.*

How to use this report

Planners and developers

The SFRA provides recommendations regarding all sources of flood risk across the borough, which can be used to inform policy on flood risk within the emerging LPU. This includes how the cumulative impact of development should be considered.

It provides the latest flood risk data and guidance to inform the sequential test, for both allocations and individual planning applications, and provides guidance on how to apply the exception test.

Links have been provided for relevant guidance documents and policies published by other RMAs such as the Lead Local Flood Authority (LLFA) and the Environment Agency (EA).

This SFRA is a strategic assessment of flood risk and does not replace the need for site-specific FRAs, where required. The SFRA provides guidance for the development industry and development management officers to establish when an FRA is required and to assess whether site-specific FRAs meet the required quality standard (Section 8.2). This should be used alongside the [EA's FRA Guidance \(gov.uk\)](https://www.gov.uk/government/uploads/system/uploads/attachment_data/file/612222/EA-FRA-Guidance.pdf). The SFRA can be used to help identify which locations and development may require emergency planning provision.

Developers need to check and ensure that new development does not increase surface water runoff rates and volumes from a site or contribute to cumulative effects of development at sensitive locations, see Section 7 and Appendix F: Cumulative Impact Assessment (CIA). Section 8.5.1 provides information on the surface water drainage requirements of the LLFA. Further assessments may also be required at this stage to manage the risk from sewer flooding to a site, and developers should contact Severn Trent Water for further advice. SuDS should be considered at the earliest stages that a site is planned to be developed which will help to minimise costs and overcome any site-specific constraints.

At the planning application stage, developers may need to undertake more detailed hydrological and hydraulic assessments of the watercourses to verify flood extent (including latest climate change allowances, last updated in May 2022), inform master-planning, and demonstrate, if required, that the exception test is satisfied.

Neighbourhood Plans

Neighbourhood planning groups can use the information in this SFRA to assess the risk of flooding to sites within their community, using Section 4, the sources of flooding across the borough and the interactive flood mapping in Appendix A. The SFRA will also be helpful for developing community level flood risk policies in high flood risk areas. Similarly, all known available recorded historical flood events across the borough are listed in Section 4.2. This can be used to supplement local knowledge regarding areas worst hit by flooding. Ongoing and proposed flood alleviation schemes planned within the borough are outlined in Section 6 and Section 8.3 discusses mitigations, resistance and resilience measures which can be applied to alleviate flood risk to an area.

Mapping

The SFRA mapping highlights on a strategic scale flood risk from fluvial, surface water and reservoirs sources, and where groundwater emergence may occur; as well as where the effects of climate change are most likely. The maps are useful to provide a community level view of flood risk but may not identify if an individual property is at risk of flooding or depict small scale changes in flood risk. Local knowledge of flood mechanisms will need to be included to complement this mapping.

The mapping data should always be supplemented by direct consultation with the relevant wastewater company to ascertain if there is any site-specific risk from a public sewer. This is because sewer flood risk information is not publicly available and would need to be considered on a site-specific basis.

Cumulative Impact Assessment (CIA)

Under the NPPF, strategic policies and their supporting SFRAs are required to 'consider cumulative impacts in, or affecting, local areas susceptible to flooding' (Paragraph 166). A Cumulative Impact Assessment (CIA) has identified which catchments in the borough are more sensitive to the cumulative impact of development and where more stringent policy regarding flood risk is recommended. Any development in these areas should seek to contribute to work that reduces wider flood risk in those catchments.

1 Introduction

1.1 Purpose of a Strategic Flood Risk Assessment (SFRA)

Tamworth Borough Council as the Local Planning Authority (LPA) are responsible for producing a Local Plan, determining planning applications, enforcement in response to breaches of planning control, and supporting neighbourhood planning.

The Council are currently compiling the evidence base to support the development of their new Local Plan which will set out land allocations and planning policies for the period 2022 to 2043, to replace their existing Local Plan 2006 to 2031 (tamworth.gov.uk).

As set out in the NPPF (Paragraph 166) “Strategic policies should be informed by a strategic flood risk assessment and should manage flood risk from all sources. They should consider cumulative impacts in, or affecting, local areas susceptible to flooding, and take account of advice from the EA and other relevant flood RMAs, such as lead local flood authorities and internal drainage boards.”

In July 2024, Tamworth Borough Council commissioned a new Level 1 SFRA to reflect the latest legislation and guidance, and to inform the updates to their Local Plan. This will supersede the 2019 SFRA, published in conjunction with the joint Southern Staffordshire Authorities of Cannock Chase Council, Lichfield District Council, Stafford Borough Council and South Staffordshire Council.

The ‘[How to prepare a Strategic Flood Risk Assessment guidance](http://gov.uk)’ (gov.uk) (last updated May 2024), sets out the requirements that the LPA must address within their SFRA and has been used to undertake this Level 1 SFRA.

As the data available for SFRAs and the relevant legislation is continually changing, an SFRA should be updated to reflect changes where applicable and reasonably practicable. Under any changes in guidance or legislation, the implications on the SFRA should be considered and a review undertaken where this is deemed reasonably necessary.

1.2 Levels of SFRA

The [PPG: Flood risk and coastal change](http://gov.uk) (gov.uk) identifies two levels of SFRA.

This is a Level 1 SFRA assessment. Level 1 SFRAs are high-level strategic documents and do not go into detail on an individual site-specific basis. Where potential site allocations are not at major flood risk and where development pressures are low, a Level 1 assessment is likely to be sufficient, without the LPA progressing to a Level 2 assessment. The Level 1 assessment should be of sufficient detail to enable application of the sequential test, to inform the allocation of development to areas of lower flood risk.

A Level 2 assessment is required where land outside flood risk areas cannot appropriately accommodate all necessary development, creating the need to apply the NPPF’s exception test, or if an LPA believe they may receive high numbers of applications in flood risk areas on sites not identified in the Local Plan. In these circumstances the assessment should

consider the detailed nature of the flood characteristics within a Flood Zone and assessment of other sources of flooding.

1.3 Study area

The study area for this SFRA is the borough of Tamworth, which is located in southeast Staffordshire, in the West Midlands of England.

The main urban area in the borough is the town of Tamworth, which is located in the north west of the region. Urban suburbs of Tamworth include Armington, Glascote Heath, Stonydelph, Hockley, Dosthill, Two Gates, and Fazeley, which is only located partially in the borough.

The study area is bounded by two other authorities, shown in Figure 1-1:

- Lichfield District
- North Warwickshire District

The water service provider for the borough is South Staffordshire Water and sewerage provider for the borough is Severn Trent Water.

The LLFA across the entire borough is Staffordshire County Council.

The key watercourses which run through the borough are the River Anker, River Tame, Kettle Brook and Fazeley Brook. These watercourses are shown in Figure 1-2.

1.4 Consultation

SFRAs should be prepared in consultation with other Risk Management Authorities (RMAs). In addition to the Council LPA the following parties have been consulted during the preparation of this version of the SFRA through data requests and draft report reviews:

- Staffordshire County Council (SCC) as LLFA
- Environment Agency (EA)
- Severn Trent Water (STW)

In addition, the following parties were consulted through data requests during the preparation of this SFRA:

- The neighbouring LPAs to provide data on cross-boundary development implications
- Canal and Rivers Trust
- Tame Valley Wetlands
- Natural England




Figure 1-1: Tamworth borough and its neighbouring authorities.




Figure 1-2: Main rivers and other watercourses across the borough.

1.5 Structure of this report

Table 1-1 sets out the contents of this Level 1 SFRA report and appendices, and how to use each section.

Table 1-1: Sets out the contents of the report and how to use each section.

Section	Contents	How to use
Executive summary	This section focuses on how the SFRA can be used by planners, developers, and neighbourhood planners.	Users should refer to this section for a summary of the Level 1 findings and recommendations.
1. Introduction	This section provides a background to the study, the Local Plan stage the SFRA informs, the borough, the roles and responsibilities for the organisations involved in flood management and how they were involved in the SFRA. It also provides a short introduction to how flood risk is assessed and the importance of considering all sources.	Users should refer to this section for general information and context.
2. Flood risk policy and strategy	This section sets out the relevant legislation, policy, and strategy for flood risk management at a national, regional, and local level.	Users should refer to this section for any relevant policy which may underpin strategic or site-specific assessments.
3. Planning policy for flood risk management	This section provides an overview of both national and existing Local Plan policy on flood risk management. This includes the Flood Zones, application of the Sequential Approach and sequential/exception test process. It provides guidance for the Councils and developers on the application of the sequential and exception test for both allocations and windfall sites, at allocation and planning application stages.	Users should use this section to understand and follow the steps required for the sequential and exception tests.
4. Understanding flood risk in the study area	This section provides an overview of the characteristics of flooding affecting the study area and key risks including historical flooding incidents, flood risk from all sources	This section should be used to understand all sources of flood risk across the study area including where has flooded

Section	Contents	How to use
	and flood warning arrangements.	historically. This section may also help identify any data gaps, in conjunction with Appendix B.
5. Impact of climate change	This section outlines the latest climate change guidance published by the EA and how this was applied to the SFRA. It also sets out how developers should apply the guidance to inform site-specific FRAs.	This section should be used to understand the climate change allowances for a range of epochs and conditions, linked to the vulnerability of a development.
6. Flood alleviation schemes and assets	This section provides a summary of current flood defences and asset management and future planned schemes. It also introduces actual and residual flood risk.	This section should be used to understand if there are any defences or flood schemes in a particular area, for further detailed assessment at site specific stage.
7. Cumulative impact of development and strategic solutions	This section introduces the Cumulative Impact Assessment (CIA), which is included as Appendix F.	Planners should use this section to help develop policy recommendations for the cumulative impact of development, in conjunction with Appendix F.
8. Flood risk management for developers	This section contains guidance for developers on FRAs, considering flood risk from all sources.	Developers should use this section to understand requirements for FRAs and what conditions/guidance documents should be followed, as well as mitigation options.
9. Surface water management and Sustainable Drainage Systems	This section provides an overview of SuDS, Guidance for developers on Surface Water Drainage Strategies, considering any specific local standards and guidance for SuDS from the LLFA.	Developers should use this section to understand what national, regional, and local SuDS standards are applicable. Hyperlinks are provided.
10. Recommendations	This section summarises sources of flood risk in the study area and outlines planning policy recommendations. It also sets out the next steps.	Developers and planners should use this as a summary of the SFRA. Developers should refer to the Level 1 SFRA recommendations when considering site specific

Section	Contents	How to use
		assessments.
Appendices	Appendix A: interactive mapping of flood risk across the borough Appendix B: details of the data available to inform the SFRA Appendix C: explains how the SFRA data should be used, including reference to relevant sections of the SFRA, how to consider different sources of flood risk and recommendations and advice for sequential and exception tests. Appendix D: summary of flood risk across the borough, highlighting key areas at risk from different sources	Planners and developers should use these appendices to understand what data has been used in the SFRA, to inform the application of the sequential and exception tests, as relevant, and to use these maps and tabulated summaries of flood risk to understand the nature and location of flood risk.

2 Flood risk policy and strategy

This section sets out the flood risk management roles and responsibilities for different organisations and relevant legislation, policy, and strategy.

2.1 Roles and responsibilities for Flood Risk Management across the borough

There are different organisations in and around the study area that have responsibilities for flood risk management, known as Risk Management Authorities (RMAs). These are listed in Table 2-1 with a summary of their responsibilities.

Further information on the roles and responsibilities of the RMAs is available in Annex A of the [National Flood and Coastal Erosion Risk Management Strategy \(FCERM\) \(gov.uk\)](#) for England.

The [Local Government Association \(gov.uk\)](#) also provide further information on the roles and responsibilities for managing flood risk.

The [National flood risk standing advice for local planning authorities \(gov.uk\)](#) provides advice on when to consult the EA.

Table 2-1: Roles and responsibilities for RMAs.

Risk Management Authority	Strategic Level	Operational Level	Planning role
EA	Strategic overview for all sources of flooding, National Strategy, and general supervision	Main River (e.g., River Tame) and reservoirs (Flood Risk Activity Permits (FRAPs), enforcement, and works)	Statutory consultee for certain development in Flood Zones 2 and 3 and all works within 20 metres of a main river.
SCC as LLFA	Coordination of Local Flood Risk Management and maintaining a Local Flood Risk Management Strategy (LFRMS)	Surface water, groundwater, and ordinary watercourses (consenting, enforcement, and works)	Statutory consultee for major developments
Severn Trent Water	Asset Management Plans, supported by Periodic Reviews (business cases),	Public sewers and some reservoirs	Non-statutory consultee

Risk Management Authority	Strategic Level	Operational Level	Planning role
	develop drainage and wastewater management plans		
Highways Authorities - National Highways for motorways and trunk roads and SCC for non-trunk roads	Highway drainage policy and planning	Highway drainage	Statutory consultee regarding highways design standards and adoptions

2.1.1 Riparian ownership

Land and property owners are responsible for the maintenance of watercourses either on or next to their properties, called Riparian Owners. Riparian Owners are also responsible for the protection of their properties from flooding as well as other management activities, for example by maintaining riverbeds/ banks, controlling invasive species, and allowing the flow of water to pass without obstruction. More information can be found on the Government website in the EA publication '[Owning a watercourse](#)' ([gov.uk](#)).

When it comes to undertaking works to reduce flood risk, the EA, and SCC as LLFA do have permissive powers, but limited resources must be prioritised and targeted to where they can have the greatest effect. Permissive powers mean that RMAs are permitted to undertake works on watercourses but are not obliged.

2.2 Relevant legislation

The following legislation is relevant to development and flood risk in the study area. Hyperlinks are provided to external documents:

- [Town and Country Planning Act \(1990\)](#) ([gov.uk](#)), [Water Industry Act \(1991\)](#) ([gov.uk](#)), [Land Drainage Act \(1991\)](#) ([gov.uk](#)), [Environment Act \(1995\)](#) ([gov.uk](#)), which set out the regulations for development on land in England and Wales.
- [Flood and Water Management Act \(2010\)](#) ([gov.uk](#)) – as amended and implanted via secondary legislation. These set out the roles and responsibilities for organisations that have a role in Flood Risk Management.
- The [Land Drainage Act \(1991, as amended\)](#) ([gov.uk](#)) and [Environmental Permitting Regulations \(2018\)](#) ([gov.uk](#)) also set out where developers will need to apply for additional permission (as well as planning permission) to undertake works to an ordinary watercourse or main river.

- The [Water Environment Regulations \(2017\) \(gov.uk\)](#) – these transpose the European Water Framework Directive (WFD) (2000) into law and require the EA to produce River Basin Management Plans (RBMPs). These aim to improve/maintain the water quality of aquatic ecosystems, riparian ecosystems, and wetlands so that they reach 'good' status.
- The [Environment Act 2021 \(gov.uk\)](#) requires developers to provide Biodiversity Net Gain (BNG) and for LPAs to develop Local Nature Recovery Strategies (LNRS). Strategic site allocations in Local Plans which present opportunities for BNG or areas for habitat improvement/creation identified by the LNRS could have parallel opportunities to contribute to reduced flood risk from a range of sources.
- Other environmental legislation such as the [Habitats Directive \(1992\) \(gov.uk\)](#), [Environmental Impact Assessment Directive \(2014\) \(gov.uk\)](#), and [The Environmental Assessment of Plans and Programmes \(Amendment\) Regulations 2020 \(gov.uk\)](#) also apply as appropriate to strategic and site-specific developments to guard against environmental damage.
- The [Planning and Compulsory Purchase Act \(2004\) \(gov.uk\)](#) Section 19(1A) requires local planning authorities to include in their Local Plans 'policies designed to secure that the development and use of land in the local planning authority's area contribute to the mitigation of, and adaptation to, climate change.'

2.3 Key national, regional, and local policy documents and strategies

Table 2-2 summarises relevant national, regional, and local flood risk policy and strategy documents and how these apply to development and flood risk. Hyperlinks are provided to external documents. These documents may:

- Provide useful and specific local information to inform FRAs within the local area.
- Set the strategic policy and direction for flood risk management and drainage – they may contain policies and action plans that set out what future flood mitigation and climate change adaptation plans may affect a development site. A developer should seek to contribute in all instances to the strategic vision for flood risk management and drainage in the study area.
- Provide guidance and/or standards that inform how a developer should assess flood risk and/or design flood mitigation and SuDS.

The following sections provide further details on some of these documents and strategies.

Please note that the links to these documents may change over time and any requests for these documents should be directed toward the author.

Table 2-2: National, regional, and local flood risk policy and strategy documents.

Policy level	Document, lead author and date	Contextual information	Policy and measures	Development design requirements	Next update due
National	Flood and Coastal Management Strategy (EA) 2020 (gov.uk)	Yes	Yes	No	2026
National	National Planning Policy Framework updated in December 2023 (gov.uk)	Yes	Yes	Yes	-
National	Planning Practice Guidance (PPG): Flood risk and coastal change (gov.uk) updated in August 2022	Yes	Yes	Yes	-
National	Building Regulations Part H (MHCLG) 2010 (gov.uk)	Yes	No	Yes	-
Regional	River Trent Catchment Flood Management Plan (2010) (gov.uk)	Yes	Yes	No	-
Regional	Humber River Basin District Management Plan (2022) (gov.uk)	Yes	Yes	No	-
Regional	Severn Trent Water Resources Management Plan (2019) (severntrent.com)	Yes	No	No	-
Regional	Severn Trent Drainage and Wastewater Management Plan (2023)	Yes	No	No	-
Regional	Climate change guidance for development and flood risk (EA) last updated May 2022 (gov.uk)	Yes	No	Yes	-
Local	Staffordshire Preliminary Flood Risk Assessment (2011) (gov.uk)	Yes	No	No	-
Local	Staffordshire Preliminary Flood Risk Assessment Addendum (2017) (gov.uk)	Yes	No	No	-
Local	Southern Staffordshire Outline Water Cycle Study Addendum (2011) (gov.uk)	Yes	Yes	Yes	-

2.3.1 The National Flood and Coastal Erosion Risk Management Strategy for England (2020)

The [National Flood and Coastal Erosion Risk Management Strategy for England \(gov.uk\)](https://www.gov.uk/government/uploads/system/uploads/attachment_data/file/86222/national-flood-and-coastal-erosion-risk-management-strategy-for-england-2020.pdf) provides the overarching framework for future action by all RMAs to tackle flooding and coastal erosion in England. The Strategy looks ahead to 2100 and the actions needed to address the challenge of climate change.

The Strategy has been split into three high level ambitions:

- Climate resilient places
- Today's growth and infrastructure resilient in tomorrow's climate
- A nation ready to respond and adapt to flooding and coastal change.

Measures within the Strategy include:

- Updating the national river, coastal, and surface water flood risk mapping and producing a new set of long-term investment scenarios to improve understanding of future risk and investment needs.
- Trialling new and innovative funding models to contribute to the investment needs for flood and coastal resilience.
- Flood resilience pilot studies.
- Developing an adaptive approach to the impacts of climate change by seeking nature-based solutions towards flooding and erosion issues, integrating Natural Flood Management (NFM) into the new Environmental Land Management scheme, and considering long term adaptive approaches in Local Plans.
- Maximising the opportunities for flood and coastal resilience as part of contributing to environmental net gain for development proposals, investing in flood risk infrastructure that supports sustainable growth, and developing world leading ways of reducing the carbon and environmental impact from the construction and operation of flood and coastal defences.
- Aligning long term strategic planning cycles for flood and coastal work between stakeholders.
- Consistent approaches to asset management and record keeping.
- Updating guidance on managing high risk reservoirs considering climate change.
- Development of digital tools to communicate flood risk, transforming the flood warning service, supporting communities to plan for flood events, increasing flood response and recovery support, and mainstreaming property flood resilience measures and 'building back better' after flooding.

The Strategy was laid before parliament in July 2020 for formal adoption and published alongside a [Policy Statement for Flood and Coastal Erosion Risk Management \(gov.uk\)](https://www.gov.uk/government/uploads/system/uploads/attachment_data/file/86222/national-flood-and-coastal-erosion-risk-management-strategy-for-england-2020.pdf). The statement sets out five key commitments which will accelerate progress to better protect and better prepare the country for the coming years:

1. Upgrading and expanding flood defences and infrastructure across the country,
2. Managing the flow of water to both reduce flood risk and manage drought,

3. Harnessing the power of nature to not only reduce flood risk, but deliver benefits for the environment, nature, and communities,
4. Better preparing communities for when flooding and erosion does occur, and
5. Ensuring every area of England has a comprehensive Local Plan for dealing with flooding and coastal erosion.

It can be expected that the implementation of the National Strategy will lead to the publication of new guidance and practice that is focused on resilience and adaptation over the coming years. It will be important to adjust the content of the SFRA so that changes in approach are captured in the delivery of the Local Plan.

2.3.2 Flood Risk Regulations (2009)

The Flood Risk Regulations (FRRs) 2009 translated the European Union (EU) Floods Directive into UK law, setting the requirement for Member States to complete an assessment of flood risk, known in England as a Preliminary Flood Risk Assessment (PFRA). This information was then used to identify areas where there is a significant risk of flooding (Flood Risk Areas), where States had to undertake Flood Risk and Hazard Mapping and produce Flood Risk Management Plans (FRMPs). This cycle was repeated on a six-yearly basis.

As of 1 January 2024, the Retained EU Law (Reform and Revocation) Bill automatically repealed any retained EU law (REUL) not otherwise preserved or replaced in UK law before the end of 2023, including the FRRs 2009 which transposed the EU Floods Directive into legislation. This is because much of the FRRs is duplicated in existing domestic legislation, namely the Flood and Water Management Act 2010. The EA and LLFAs in England will therefore no longer be required to comply with a third cycle of planning, however the government expects to see continued implementation of the FRMPs 2021-2027. The objectives and measures from the second cycle FRMPs are presented in the [EA Flood Plan Explorer \(gov.uk\)](https://www.gov.uk/government/publications/ea-flood-plan-explorer).

The [SCC PFRA Addendum \(2017\)](#) identified no Indicative Flood Risk Area (IFRA) within the SCC administrative boundary.

The [EA PFRA \(2018\)](#) for river, seas and reservoir flooding identified 40 Flood Risk Areas in the Humber RBD, with none of these affecting the Borough.

2.3.3 Flood and Water Management Act (2010)

The FWMA was passed in April 2010 following the recommendations made within the Pitt Review (2009) following the flooding in 2007. It aims to improve both flood risk management and the way water resources are managed.

The FWMA has created clearer roles and responsibilities and helped to define a more risk-based approach to dealing with flooding. This included the creation of a lead role for Local Authorities, as LLFAs, designed to manage local flood risk (from surface water, ground water and ordinary watercourses) and to provide a strategic overview role of all flood risk for the EA. Schedule 3 of the FWMA 2010 is expected to be implemented by the

government following periods of consultation, making SuDS mandatory for new developments in England. Further information on Schedule 3 is provided in Section 9.1.

The content and implications of the FWMA provide considerable opportunities for improved and integrated land use planning and flood risk management by Local Authorities and other key partners. The integration and synergy of strategies and plans at national, regional, and local scales is increasingly important to protect vulnerable communities and deliver sustainable regeneration and growth.

2.3.4 The Water Framework Directive and Water Environment Regulations and River Basin Management Plans

The purpose of the WFD is to deliver improvements across Europe in the management of water quality and water resources through a series of plans called RBMPs for each River Basin District. The EA manages the RBMPs and must review and update them every six years. The first cycle of RBMPs were published in 2009 and were most recently updated in 2022. The borough falls under the [Humber RBMP](#).

2.3.5 Catchment Flood Management Plans

Tamworth Borough lies within the [River Trent CFMP](#) area and falls within Sub-area 6: Mid Staffs and Lower Tame. Sub Area 6 has preferred Policy Option 6 - Areas of low to moderate flood risk where action can be taken with others to store water or manage run-off in locations that provide overall flood risk reduction or environmental benefits.

Proposed actions in this area relevant to the Council LPU include:

- Identifying locations where flood attenuation ponds or wetland areas could be developed with associated habitat improvement or creation.
- Complete strategy for the River Tame, focussing on opportunities to naturalise the river in rural areas to reduce flood risk in Tamworth.
- Providing a more accurate and community focused flood warning service.

2.3.6 Local Flood Risk Management Strategy (LFRMS)

The LFRMS for Tamworth ([gov.uk](https://www.gov.uk)), published in 2017, sets out seven key strategy objectives for managing local flood risk in Staffordshire. These are:

- Developing a strategic understanding of flood risk from all sources
- Promoting effective management of drainage and flood defence systems
- Supporting communities to understand flood risk and become more resilient to flooding
- Managing local flood risk and new development in a sustainable manner
- Achieving results through partnership and collaboration
- Be better prepared for flood events
- Secure and manage funding for flood risk management in a challenging financial climate

An update to the LFRMS in 2024, aims to ensure that flood risk in Staffordshire is reduced by maximising opportunities through innovative, ambitious and sustainable means. The updated LFRMS identifies five strategy objectives. These are:

- Improving understanding of flood risk and preparing for flood events
- Managing flood risk and new development in a sustainable manner
- Seeking and securing funding for flood alleviation schemes and collaboration with partners
- Working with others to ensure communities are more aware, informed and resilient to flooding.
- Promoting effective management of drainage and flood defence assets.

2.3.7 Local policy and guidance for SuDS

The 2024 NPPF states that: 'Applications which could affect drainage on or around the site should incorporate sustainable drainage systems to control flow rates and reduce volumes of runoff, and which are proportionate to the nature and scale of the proposal.' (Paragraph 182) and 'development should only be allowed in areas at risk of flooding where... it can be demonstrated that... c) it incorporates sustainable drainage systems, unless there is clear evidence that this would be inappropriate' (Paragraph 181). When considering major planning applications, local planning authorities (LPAs) should consult the relevant LLFA on the management of surface water to satisfy that:

- The proposed minimum standards of operation are appropriate.
- Using planning conditions or planning obligations there are clear arrangements for on-going maintenance over the development's lifetime.

At the time of writing this SFRA, the following documents and policies are relevant to SuDS and surface water in the study area. Hyperlinks are provided to external documents:

- [SuDS Manual \(C753\) \(ciria.org\)](https://www.ciria.org/publications/suds-manual-c753/), published in 2007 and updated in 2015.
- [Defra Non-statutory technical standards for sustainable drainage systems \(gov.uk\)](https://www.gov.uk/government/publications/defra-non-statutory-technical-standards-for-sustainable-drainage-systems), 2015
- [Defra National Standards for sustainable drainage systems Designing, constructing \(including LASOO best practice guidance\), operating, and maintaining drainage for surface runoff \(gov.uk\)](https://www.gov.uk/government/publications/defra-national-standards-for-sustainable-drainage-systems), 2011
- [Building Regulations Part H \(MHCLG\) \(gov.uk\)](https://www.gov.uk/government/publications/building-regulations-part-h), 2010
- [SCC LLFA SuDS Guidance and LLFA Pro-forma checklist \(staffordshire.gov.uk\)](https://staffordshire.gov.uk/scc-llfa-suds-guidance-and-llfa-pro-forma-checklist)

The 2023 NPPF states that flood risk should be managed "using opportunities provided by new development and improvements in green and other infrastructure to reduce the causes and impacts of flooding" (Paragraph 167). Alongside flood risk management, SuDS can provide amenity, biodiversity, recreation, community, and water resources benefits. Where possible, priority should be given to SuDS that can deliver multiple benefits.

2.3.8 Water Cycle Studies

Water Cycle Studies (WCSs) assist local authorities to select and develop growth proposals that minimise impacts on the environment, water quality, water resources, infrastructure, and flood risk and help to identify ways of mitigating such impacts.

The [Southern Staffordshire Outline Water Cycle Study \(WCS\) Addendum](#) was completed for five Local Authority areas (Stafford Borough, Lichfield District, Tamworth Borough, Cannock Chase District and South Staffordshire District) in southern Staffordshire in 2010.

2.3.9 Surface Water Management Plans

Surface Water Management Plans (SWMPs) outline the preferred surface water management strategy in a given location and establish a long-term action plan to manage surface water in a particular area. They are intended to influence future capital investment, drainage maintenance, public engagement and understanding, land-use planning, emergency planning, and future developments.

In 2011, a Phase 1 and Phase 2 [Surface Water Management Plan \(SWMP\)](#) was published for five Local Authority Areas in the South Staffordshire region (see Section 2.3.8 for a list of Local Authorities).

2.3.10 Water Resources Management Plans (WRMPs)

Under the duties set out in sections 37A to 37D of the Water Industry Act 1991, all water companies across England and Wales must prepare and maintain a WRMP. This must be prepared at least every five years and reviewed annually.

WRMPs should set out how a water company intends to achieve a secure supply of water for their customers and a protected and enhanced environment.

Severn Trent Water published their WRMP 2019 ([severntrent.com](https://www.severntrent.com)) in August 2019. The draft WRMP ([dWRMP 2024](#)) plan provides an update to the 2019 report, setting a long-term strategy for the next 25 years and looking ahead to 2085 to help prepare for the future. It demonstrates long-term plans to accommodate the impacts of population growth, drought, environmental obligations, and climate change

2.3.11 Drainage and Wastewater Management Plans (DWMPs)

Water and sewage companies must produce a Drainage and Wastewater Management Plan (DWMP), covering a minimum of 25 years, which looks at current and future capacity, pressures, and risks to their networks such as climate change and population growth. They detail how a company plans to work with RMAs and drainage asset owners to manage future pressures. The water and sewage company for the study area is Severn Trent Water.

Severn Trent Water's DWMP [Final 2023] ([severntrent.com](https://www.severntrent.com)) provides evidence to support and inform their PR24 business plan, which covers the period from 2025 to 2030. The Severn Trent Water DWMP sets out a long-term strategic plan that will set out how wastewater systems, and the drainage networks that impact them, are to be extended,

improved and maintained to ensure they are robust and resilient for the next 25 years, until 2050. Severn Trent Water's aim is 'To extend, improve and maintain robust and resilient drainage and wastewater systems against future pressures such as climate change, population growth and urbanisation.'

3 Planning policy for flood risk management

This section summaries national planning policy for development and flood risk.

3.1 National Planning Policy Framework and Guidance

The [NPPF \(December 2024\) \(gov.uk\)](#) sets out the Government's planning policies for England. It must be considered in the preparation of Local Plans and is a material consideration in planning decisions. The NPPF advises on how flood risk should be considered to guide the location of future development and FRA requirements. The NPPF states that:

“Strategic policies should be informed by a strategic flood risk assessment and should manage flood risk from all sources. They should consider cumulative impacts in, or affecting, local areas susceptible to flooding, and take account of advice from the Environment Agency and other relevant flood risk management authorities, such as lead local flood authorities and internal drainage boards” (Paragraph 171).

The [Flood Risk and Coastal Change PPG \(gov.uk\)](#), last updated August 2022, sets out how the policy should be implemented. Diagram 1 in the PPG (Paragraph: 007 Reference ID: 7-007-20220825) sets out how flood risk should be considered in the preparation of Local Plans.

3.2 The sequential test

Firstly, land at the lowest risk of flooding from all sources should be considered for development. A test is applied called the ‘sequential test’ to do this. Figure 3-1 summarises the sequential test. The LPA will apply the sequential test to strategic allocations. For all other developments, evidence must be supplied to the LPA, with a planning application, that the development has passed the test if any proposed building, access and escape route, land-raising or other vulnerable element will be:

- in Flood Zone 2 or 3;
- in Flood Zone 1 and the SFRA shows it will be at increased risk of flooding in during its lifetime; or
- subject to sources of flooding other than rivers or sea,

as set out in the [FRA Standing Advice \(gov.uk\)](#). The LPA should define a suitable search area for the consideration of alternative sites in the sequential test. The sequential test can be undertaken as part of a Local Plan Sustainability Appraisal. Alternatively, it can be demonstrated through a free-standing document, or as part of Strategic Housing Land / Employment Land Availability Assessments.





Figure 3-1: The Sequential Test.

Whether any further work is needed to decide if the land is suitable for development will depend on both the vulnerability of the development and the Flood Zone it is proposed for. [Table 2 of the PPG \(gov.uk\)](#) (Paragraph: 079 Reference ID: 7-079-20220825) shows whether, having applied the Sequential Test first, the vulnerability of development is not compatible with a particular Flood Zone and where the Exception Test is required to determine the suitability of that vulnerability of development to the flood zone.

Figure 3-2 illustrates the sequential test as a process flow diagram using the information contained in this SFRA to assess potential development sites against areas of flood risk and development vulnerability compatibilities. This is a stepwise process, but a complex one, as several of the criteria used are qualitative and based on experienced judgement. The process must be documented, and evidence used to support decisions recorded.

In addition, the risk of flooding from other sources and the impact of climate change must be considered when considering which sites are suitable to allocate. Appendix C addresses the use of flood risk information in the performance of the sequential test.



† Diagram 2 of PPG: Flood Risk and Coastal Change (paragraph 026, Reference ID 7-026-20220825) Revised August 2022.

Figure 3-2: Application of the sequential test for plan preparation.

3.2.1 The risk-based approach

The NPPF takes a risk-based approach to development in flood risk areas.

Since July 2021, the approach has adjusted the requirement for the sequential test (as defined in Paragraph 167 of the NPPF) so that all sources of flood risk are to be included in the consideration.

The updated PPG further states in Paragraph 23 of the Flood risk and coastal change guidance: "Other forms of flooding need to be treated consistently with river and tidal flooding in mapping probability and assessing vulnerability, so that the sequential approach can be applied across all areas of flood risk".

The general implications of these are summarised as follows:

- The Sequential Test must be based on mapping that enables decision making according to a prioritisation based on a risk-based sequence (for river and sea flooding national mapping is available that describes low, medium and high-risk flood zones but comparable mapping of this specific type and quality is not available for other sources; for river and sea flooding the risk zones are based on the assumption that no flood risk management features are present).
- The other sources of flood risk that can potentially be included in the Sequential Test are surface water, groundwater, sewer flooding and reservoir flooding.
- It follows that proposed new development placed in locations at high or medium risk from flooding from other sources now and in the future (note that the explicit requirement to include climate change in the test, as set out in the August 2022 PPG will require the preparation of additional modelling and mapping or use of proxies) should be accompanied by evidence that the Exception Test can be satisfied (in a Level 2 SFRA).

A basic requirement for the Sequential Test to be performed is that appropriate, competent mapping can be prepared to enable logical comparison of the flood risk from different sources at alternative locations, both now and in the future, as this is fundamental to establishing a logical “risk sequence”.

Appendix C describes the implications of including different sources of flooding both now and in the future in the Sequential Test. It also highlights matters to be considered and identifies a preferred approach.

3.3 The Exception Test

It will not always be possible for all new development to be located on land that is not at risk from flooding. To further inform whether land should be allocated, or Planning Permission granted, a greater understanding of the scale and nature of the flood risks is required. In these instances, the exception test will be required. [Diagram 3 of the PPG \(gov.uk\)](#) (Paragraph: 033 Reference ID: 7-033-20220825) summarises the Exception Test (Figure 3-3).

[Table 2 of the PPG \(gov.uk\)](#) sets out the requirements for the exception test but does not reflect the need to avoid flood risk from sources other than rivers and the sea. There is no guidance on how to consider other sources of flood risk. The exception test should only be applied, following the application of the sequential test, in the following instances:

- 'Essential infrastructure' in Flood Zone 3a or 3b
- 'Highly vulnerable' development in Flood Zone 2 (this is NOT permitted in Flood Zone 3a or 3b)
- 'More vulnerable' development in Flood Zone 3a (this is NOT permitted in Flood Zone 3b)

While the exception test is not explicitly required for sites at risk from other sources of flooding, Tamworth Borough Council should follow a similar principle where sites are

proposed that are at risk from other sources of flooding, carefully weighing up the wider benefits of development against the risk, ensuring that site users can be kept safe through the lifetime of the development and ensuring residual risk can be safely managed.

For sites proposed for allocation within the Local Plan, the LPA should use the information in this SFRA to inform the exception test. At the planning application stage, the developer must design the site such that it is appropriately flood resistant and resilient in line with the recommendations in national and local planning policy and supporting guidance and those set out in this SFRA. This should demonstrate that the site will still pass the flood risk element of the exception test based on the detailed site level analysis.




Diagram 3 of PPG: Flood Risk and Coastal Change (paragraph 033, Reference ID 7-033-20220825) Revised August 2022.

Figure 3-3: Application of the exception test to plan preparation.

There are two parts to demonstrating a development passes the exception test that should be considered by the LPA when allocating development sites, and developers when required (see Section 3.4.2 for exception test requirements for individual planning applications).

Part A: Demonstrating that the development would provide wider sustainability benefits to the community that outweigh the flood risk.

The LPA will need to set out the criteria used to assess the exception test and provide clear advice to enable applicants to provide evidence to demonstrate that it has been passed. If the application fails to prove this, the LPA should consider whether the use of planning conditions and / or planning obligations could allow it to pass the exception test. If this is not possible, this part of the exception test has failed, and planning permission should be refused.

Wider sustainability objectives should be considered, such as those set out in Local Plan Sustainability Appraisals. These generally consider matters such as biodiversity, green infrastructure, housing, historic environment, climate change adaptation, flood risk, green energy, pollution, health, transport etc.

The sustainability issues the development will address and how far doing so will outweigh the flood risk concerns for the site should also be considered, e.g., by facilitating wider regeneration of an area, providing community facilities, infrastructure that benefits the wider area etc.

Part B: Demonstrating that the development will be safe for its lifetime taking account of the vulnerability of its users, without increasing flood risk elsewhere, and, where possible, will reduce flood risk overall.

In circumstances where the potential effects of proposed development are material a Level 2 SFRA is likely to be needed to inform the exception test for strategic allocations to provide evidence that the principle of development can be supported. At the planning application stage, a site-specific FRA will be needed. Both will need to consider the actual and residual risk and how this will be managed over the lifetime of the development.

3.4 Applying the sequential test and exception test to individual planning applications

3.4.1 Applying the sequential test

Tamworth Borough Council, with advice from the EA, are responsible for considering the extent to which sequential test considerations have been satisfied.

Developers are required to apply the sequential test to all development sites, unless the site is:

- A strategic allocation and the test has already been carried out by the LPA as part of preparing the Local Plan, or
- A change of use (except to a caravan, camping or chalet site, or to a mobile home or park home site), or
- A minor development (householder development, small non-residential extensions with a footprint of less than 250m²), or

- A development in fluvial Flood Zone 1 unless there are other flooding issues in the area of the development (i.e. surface water, groundwater, reservoir, sewer flooding).

It should also be noted that residential sub-divisions are exempted from the definition of minor development and therefore, by default, should also be subject to the sequential test.

The SFRA contains information on all sources of flooding and takes into account the impact of climate change. This should be considered when a developer undertakes the sequential test, including the consideration of reasonably available sites at lower flood risk.

Local circumstances must be used to define geographical scope of the sequential test (within which it is appropriate to identify reasonably available alternatives). To determine the appropriate search area criteria, include the catchment area for the type of development being proposed. For some sites this may be clear, e.g. school catchments, in other cases it may be identified by other Local Plan policies. For some sites, e.g. regional distribution sites, it may be suitable to widen the search area beyond LPA administrative boundaries.

The sources of information on reasonably available sites may include but is not restricted to:

- Site allocations in Local Plans
- Sites with Planning Permission but not yet built out
- Strategic Housing and Economic Land Availability Assessments (SHELAAAs)/ five-year land supply/ annual monitoring reports
- Locally listed sites for sale

It may be that a number of smaller sites or part of a larger site at lower flood risk form a suitable alternative to a development site at high flood risk.

Ownership or landowner agreement in itself is not acceptable as a reason not to consider alternatives.

3.4.2 Applying the exception test

Where a development proposal is in accordance with an allocation made in a Local Plan following the application of the sequential and exception tests, the exception test will only be required to be repeated if:

- Elements of the development that were key to it satisfying the exception test at the plan-making stage (such as wider sustainability benefits to the community or measures to reduce flood risk overall) have changed or are not included in the proposed development; or
- The understanding of current or future flood risk has changed significantly.

For developments that have not been allocated in the Local Plan or where the sequential test was not applied at the development plan stage and new information becomes available that identifies a flood risk, developers must undertake the sequential and exception tests and present this information to the LPA for approval. The Level 1 SFRA can be used to

scope the flooding issues that a site-specific FRA should investigate in more detail to inform the exception test for windfall sites.

The applicant will need to provide information that the application can pass both parts of the exception test.

4 Understanding flood risk across the borough

This section explores the key sources of flooding in the borough and the factors that affect flooding including topography, soils, and geology. The main sources of flooding affecting the study area are from watercourses and surface water as detailed in information provided by the Council, SCC, the EA, and Severn Trent Water.

This is a strategic summary of the risk in the study area to inform the application of the sequential and exceptions tests. Developers should use this section to scope out the flood risk issues they need to consider in greater detail in a site-specific FRA to support a Planning Application. Information in this section should not be used to inform flood risk at a property-level.

4.1 Defining flood risk

Section 3 (subsection 1) of the [Flood and Water Management Act 2010 \(FWMA\) \(gov.uk\)](https://www.gov.uk/government/acts/flood-and-water-management-act-2010) defines the risk of a potentially harmful event (such as flooding) as ‘a risk in respect of an occurrence is assessed and expressed (as for insurance and scientific purposes) as a combination of the probability of the occurrence with its potential consequences.’

Figure 4-1 sets out this definition of risk.




Figure 4-1: Conceptual model depicting how risk can be defined.

4.1.1 Source-Pathway-Receptor model

Flood risk can be assessed using the Source-Pathway-Receptor model where:

- The source is the origin of the floodwater, principally rainfall.
- A pathway is a route or means by which a receptor can be affected by flooding, which includes rivers, drains, sewers, and overland flow.
- A receptor is something that can be adversely affected by flooding, which includes people, their property, and the environment.

This is a standard environmental risk model common to many hazards and should be the starting point of any assessment of flood risk. All these elements must be present for flood risk to arise. Having applied the Source-Pathway-Receptor model it is possible to mitigate the flood risk by addressing the source (often very difficult), blocking, or altering the pathway, or removing the receptor, e.g., steer development away.

The planning process is primarily concerned with the location of receptors, taking appropriate account of potential sources and pathways that might put those receptors at risk. It is therefore important to define the components of flood risk to apply this guidance in a consistent manner.

4.1.2 Probability

The probability of flooding is expressed as a percentage based on the average frequency measured or extrapolated from records over many years. A 1% probability indicates the flood level that is expected to be reached on average once in a hundred years, i.e., it has a 1% chance of occurring in any one year, not that it will occur at least once every hundred years.

Considered over the lifetime of development, such an apparently low frequency or rare flood has a significant probability of occurring. For example:

- A 1% flood has a 26% (1 in 4) chance of occurring at least once in a 30-year period - the period of a typical residential mortgage.
- And a 49% (1 in 2) chance of occurring in a 70-year period - a typical human lifetime.

4.1.3 Consequences

The consequences of flooding include fatalities, property damage, disruption to lives and businesses, with severe implications for people (e.g., financial loss, emotional distress, health problems). Consequences of flooding depend on the hazards caused by flooding (depth of water, speed of flow, rate of onset, duration, wave-action effects, water quality), the receptors that are present and the vulnerability of these receptors (type of development, nature, e.g., age-structure, of the population, presence, and reliability of mitigation measures etc).

4.2 Historical flooding

The EA's Historic Flood Map (HFM) shows areas of land that have been previously subject to flooding in the area. This includes flooding from rivers, the sea and groundwater springs but excludes surface water.

The EA's Historic Flood Map (HFM) shows areas of historic flooding along the western border of the borough, following the path of the River Tame. Additionally, areas along the River Anker in the north of the borough have also experienced previous flooding.

The EA Recorded Flood Outlines dataset shows 25 areas of recorded flooding within the borough, caused by three individual flooding events:

- June 1955 (Upper Trent) - fluvial flooding due to channel capacity exceedance along the River Tame and River Anker in the northern part of the borough.
- 1992 - fluvial flooding along the River Anker in the northern part of the borough and River Tame along the western boundary.

- July 2007 - fluvial flooding due to channel capacity exceedance along the River Tame in the northwestern part of the borough.

Information on sewer flooding across the study area is included in Section 4.6 and a list of historic flooding incidences provided by Severn Trent Water is available in Table 4-1.

Staffordshire County Council have also provided data on flooding hotspots within Tamworth Borough. This indicates that between 1990 and 2024, 64 incidents of flooding have been recorded. The town of Tamworth is shown to have the highest prevalence of incidences, with several incidences in surrounding areas including Hockley, Amington and Glascote.

4.2.1 Section 19 Flood Investigations

Under the Flood and Water Management Act (2010), the Lead Local Flood Authority (LLFA) has a duty to investigate flood incidences, where considered necessary or appropriate and produce a report.

Section 19 Flood Investigation reports for the Staffordshire District are available on the council website ([Staffordshire.gov.uk](https://www.staffordshire.gov.uk)). One Section 19 report for the Staffordshire County encompasses the area of Tamworth:

- October 2019 Flood Event: Section 19 Investigation Report for the Staffordshire County Area. One property was reported to have experienced internal flooding in Tamworth as a result of heavy rainfall on 25th and 26th October 2019. Over 70 properties flooded countywide.




Figure 4-2: Locations of historic flooding from the EA's Historic Flood Map.

4.3 Topography, geology, and soils

The topography, geology and soil are all important in influencing the way the catchment responds to a rainfall event. The degree to which a material allows water to percolate through it, the permeability, affects the extent of overland flow and therefore the amount of run-off reaching the watercourse. Steep slopes or clay rich (low permeability) soils will promote rapid surface runoff, whereas more permeable rock such as limestone and sandstone may result in a more subdued response.

4.3.1 Topography

Figure 4-3 shows the topography of the study area. The topography of Tamworth borough is characterised by the low-lying land of the River Tame and River Anker in the north and west. Steeper topographies are present in the southeast of the borough towards Glasgote Heath, Stonydelph and Hockley. The highest elevation in the southeastern corner of the borough is roughly 115m AOD in the settlement of Hockley.

In the north and west areas of the borough, along the River Tame and River Anker, elevations are much lower, at around 57m AOD. The town of Tamworth is also characterised by low-lying land, with elevations of approximately 65m AOD in the southern part of the town.

4.3.2 Geology

In the northwestern part of the borough, the bedrock geology consists of Mudstone, which is poorly draining. In central and eastern parts of the borough, mudstone is also present, as well as sandstone and siltstone, which are more freely draining. A map detailing the extents of this bedrock and further superficial geology across the borough can be viewed online in the British Geology Society Geology Viewer (bgs.ac.uk).

Drainage from new development sites or redeveloped sites should be designed in line with the drainage hierarchy (see Section 8.2.3) which initially promotes the use of infiltration prior to considering alternative drainage. Most types of SuDS will be suitable in areas with permeable bedrock including features such as soakaways and infiltration basins. In areas with more impermeable geology, off-site discharge in accordance with the drainage hierarchy may be required to discharge surface water runoff from the site. In some cases, above-ground features such as attenuation ponds may be practical with a managed outlet or discharge point. Infiltration testing should be undertaken on site prior to development where infiltration drainage features are proposed. Further information on SuDS can be found in Section 9.

The EA also provides mapping of different types of aquifers, the underground layers of water-bearing permeable rock from which groundwater can be extracted. Aquifers are designated as either principal or secondary aquifers. Principal aquifers are designated by the EA as strategically important rock units that have high permeability and water storage capacity.

The largest aquifer coverage is Secondary A which covers the majority of the borough. There is also a large area in the western part of the study area characterised by a Secondary B aquifer. A Principal aquifer is also present within a small region in the north of the borough. Aquifer designations across the borough for bedrock geology are shown in Figure 4-4.

4.3.3 Soils

In general, the soils across the borough are loamy and clayey, with reduced permeability which may impact potential infiltration across the borough and would need to be considered within any SuDS design (see Section 9 for further information on SuDS).

In the northern region, soils are slightly acidic, loamy and clayey, as well as slowly permeable. In the central and western parts of the borough, including the town of Tamworth and floodplains of the River Tame and River Anker, soils are loamy and clayey with naturally high groundwater. Within the eastern area, including the areas of Stonydelph and Wilnecote, slowly permeable, seasonally wet, acidic loamy and clayey soils are present.

The British Geological Survey website (bgs.ac.uk) provides data on soils across the borough.




Figure 4-3: EA 1m LiDAR data showing the topography across the borough.




Figure 4-4: Aquifer designations based on bedrock geology across the borough.

4.4 Fluvial flood risk

4.4.1 Flood Zones

Fluvial flood risk across the borough is assessed based on Flood Zones. The definition of the Flood Zones is provided below. The Flood Zones do not consider defences, except when considering the functional floodplain. This is important for planning long term developments as long-term policy and funding for maintaining flood defences over the lifetime of a development may change over time.

The Flood Zones are:

- Flood Zone 1: Low risk: less than a 0.1% chance of river flooding in any given year.
- Flood Zone 2: Medium risk: between a 1% and 0.1% chance of river flooding in any given year.
- Flood Zone 3a: High risk: between a 3.3% and 1% chance of river flooding in any given year.
- Flood Zone 3b: Functional Floodplain: land where water has to flow or be stored in times of flood (greater than a 3.3% chance of river flooding in any given year). Only water compatible and essential infrastructure are permitted in this zone and should be designed to remain operational in times of flood, resulting in no loss of floodplain or blocking of water flow routes. [Annex 3 of the NPPF \(gov.uk\)](#) provides information on flood risk vulnerability.

Important note on Flood Zone information in this SFRA

The Flood Zone maps for the study area are provided in Appendix A: GeoPDFs.

Flood Zones 2 and 3a within this SFRA show the same extent as the online EA's Flood Map for Planning (FMfP) (which incorporates latest modelled data) except for the Lower Tame 2023 model. Here, the latest undefended model outputs have been used in preference to the EA's FMfP. These extents are shown in the Appendix A: GeoPDFs as Modelled Flood Zones 2 and 3a.

In agreement with the EA, the River Anker model was not used to inform Flood Zones 2 and 3a, due to its age and uncertainty around the model outputs in this location. Instead, the EA FMfP should be used in this location.

The EA Flood Zones do not cover all catchments or ordinary watercourses with areas <3km². As a result, whilst the EA Flood Zones may show an area is in Flood Zone 1, there may be a flood risk from a smaller watercourse(s) not shown in the Flood Zones.

Flood defences should be considered when delineating the functional floodplain. Due to the absence of 3.3% outputs in the available EA models, the 3.3% AEP defended layer, released as part of NaFRA2, has been used. In the Tamworth area, this layer is based on the EA's New National Model (NNM), therefore further work should be undertaken as part of

a detailed site-specific FRA to define and refine the extent of Flood Zone 3b where no detailed modelling exists. The EA are undertaking further detailed modelling of the River Tame, once this becomes available this is likely to supersede the national modelling used.

Further details on the specific model extents used are provided in Appendix B. There are no EA designated Flood Storage Areas within the borough.

4.4.2 Fluvial flood risk across the borough

The major watercourses flowing through the borough are:

- The River Tame
- River Anker and its tributaries including the Kettle Brook

Tributaries of these watercourses include smaller ordinary watercourses and numerous unnamed drains. There are also several ponds and lakes within the study area. A map of the key watercourses is included in Figure 1-2 and in Appendix A: GeoPDFs.

The primary fluvial flood risk in the borough is where these watercourses run through developed areas. For example, the River Tame and River Anker both run through the town of Tamworth in the northern part of the borough. Areas including Coton Farm, Lichfield Road Industrial Estate, Ventura Retail Park and residential estates south of the A5 by the border are within fluvial Flood Zones associated with the River Tame. Fluvial flood extents associated with the River Anker affect some areas in Amington and Bolehall in the northeast of the borough. The Kettle Brook also poses risk of fluvial flooding to properties in Wilnecote and Kettlebrook.

The flood risk associated with the major locations in the borough are further detailed in Appendix D. The impacts of climate change on fluvial flooding are discussed in Section 5.3.1.

4.5 Surface water flooding

Surface water runoff is most likely to be caused by intense downpours e.g. thunderstorms. At times the amount of water falling can completely overwhelm the drainage network, which is not designed to cope with extreme storms. The flooding can also be complicated by blockages to drainage networks, sewers being at capacity and/ or high-water levels in watercourses that cause local drainage networks to back up.

The EA Risk of Flooding from Surface Water mapping (RoFSW) dataset released as part of NaFRA2 in December 2024 has been used to assess flood risk to the borough. The RoFSW highlights several communities in the study area at risk from surface water flooding. Surface water flow paths generally follow the topography of existing watercourses, although there are some areas at risk from isolated ponding. Additionally, surface water flow routes are also established on roads and in more urban areas within Tamworth, highlighting risk to transport networks while posing a risk to buildings which water can be routed to.

In particular, there are prominent overland flow paths established along a significant portion of the River Anker floodplain in the northeast, flowing west. While this affects primarily rural land, there are also considerable flow paths and isolated areas of ponding in urban areas across the entire borough. This includes properties and infrastructure in Dosthill (predominantly from Hockley to Hedging Lane), Two Gates and Belgrave in the south, Stonydelph (converging south-west at the nature reserve), Glascote and Amington in the east (converging north around Brindley Drive and the railway embankment), and Leyfields (including impounding along the railway embankment) and around the County Drive estate north of Fazeley in the west. Additionally, main transport links including the A5, as well as both the Trent Valley and Derby-to-Birmingham railway lines, are also shown to be at risk of surface water flooding. The RoFSW mapping for the study area can be found in Appendix A: GeoPDFs.

The impacts of climate change on surface water flooding are discussed in Section 5.3.2.

4.6 Sewer flooding

Sewer flooding occurs when intense rainfall/river flooding overloads sewer capacity (surface water, foul or combined), and/or when sewers cannot discharge to watercourses due to high water levels. Sewer flooding can also be caused by blockages, collapses, equipment failure or groundwater leaking into sewer pipes.

Since 1980, the Sewers for Adoption guidelines mean that new surface water sewers have been designed to have capacity for a 3.3% AEP rainfall event, although until recently this did not apply to smaller private systems. This means that sewers can be overwhelmed in larger rainfall and flood events.

New developments should not cause additional pressures on existing sewers due to the requirements to maintain greenfield runoff rates. However, increases in rainfall as a result of climate change can lead to existing sewers becoming overloaded, although this can be reduced through the use of well-designed SuDS to reduce surface water runoff.

Severn Trent Water is the water company responsible for the management of the sewerage networks across the study area. Severn Trent Water provided their Hydraulic Sewer Flooding Risk Register for the borough which includes a list of properties which have reported at least one incidence of external or internal sewer flooding between June 1997 and August 2024. It should be noted that multiple incidences have been recorded at some properties. Table 4-1 displays this data using truncated postcodes to avoid identifying specific streets or properties. The general area covered by the postcode is also detailed.

Table 4-1: Properties with sewer flooding incidences recorded by Severn Trent Water (June 1997 and August 2024).

Postcode	No. of properties with at least one recorded incident	Area covered by postcode
B77 1	2	Two Gates and Dosthill
B77 2	12	Belgrave and Glascote Heath
B77 3	5	Tamworth (east)- Bolehall
B77 4	1	Amington and Stonydelph
B77 5	3	Hockley
B78 3	5	Fazeley
B79 7	8	Tamworth (west)- Lichfield Road and Coton Farm
B79 8	6	Tamworth (north)- Leyfields

4.7 Groundwater flooding

In general, less is known about groundwater flooding than other sources of flooding and availability of data is limited. Groundwater flooding can be caused by:

- High water tables, influenced by the type of bedrock and superficial geology.
- Seasonal flows in dry valleys, which are particularly common in areas of chalk geology.
- Rebounding groundwater levels, where these have been historically lowered for industrial or mining purposes.
- Where there are long culverts that prevent water easily getting into watercourses.
- Perched aquifers underlain by impermeable geology, particularly in low lying areas.

Groundwater flooding is different to other types of flooding. It can last for days, weeks, or even months and is much harder to predict and warn for. Monitoring does occur in certain areas, for example where there are major aquifers or when mining stops.

The JBA Groundwater Emergence map and the EA AStGWF dataset for the study area, shown in Appendix A, have been used to identify potential areas that are likely to be at higher risk of groundwater flooding. The EA AStGWF map shows that, overall, a large part of the northwest has a greater than 75% susceptibility to groundwater flooding, as well as an area in the northeast where an unnamed tributary leads to Mallard Halt. There are areas with greater than 50% susceptibility in Coton Farm, Dosthill, between the Tamworth Railway Station and Amington, and the rural lands north of Anker Valley Sports Complex. The JBA Groundwater Emergence Map reflects this, with significant parts of the northwest and northeast having groundwater levels that are at or very near (within 0.025m of) the ground surface. In the northwest, this includes Coton Farm, Lichfield Road Industrial Estate, and the north of Fazeley. In the northeast, this encompasses the rural areas surrounding the River Anker. There are further regions with groundwater emergence levels either at or

very near (within 0.025m of) the ground surface by the River Tame north of Dosthill, and between Stonydelph and Wilnecote.

It should be noted that these datasets only identify areas likely to be at risk of groundwater emergence and do not allow prediction of the likelihood of groundwater flooding or quantification of the volumes of groundwater that might be expected to emerge in a given area. Further details on the datasets are provided in Appendix B.

The areas at most risk of groundwater emergence are discussed further in Appendix D. In high-risk areas, a site-specific risk assessment for groundwater flooding may be required to fully inform the likelihood of flooding.

4.8 Flooding from reservoirs

Reservoirs with an impounded volume greater than 25,000 cubic metres are governed by the [Reservoirs Act 1975 \(gov.uk\)](https://www.gov.uk/government/legislation/the-reservoirs-act-1975) and are on a register held by the EA. The level and standard of inspection and maintenance required by a Supervising Panel of Engineers under the Act means that the risk of flooding from reservoirs is very low. Some reservoirs are designated as high risk by the EA, where an uncontrolled release of water could put people's lives at risk and are subject to increased inspection and maintenance requirements. However, this designation does not mean they are at a high risk of flooding.

Flooding from reservoirs occurs following partial or complete failure of the control structure designed to retain water in the artificial storage area. Reservoir flooding is very different from other forms of flooding; it may happen with little, or no warning and evacuation will need to happen immediately. The likelihood of such flooding is difficult to estimate but is extremely low compared to flooding from other sources. It may not be possible to seek refuge upstairs from floodwater as buildings could be unsafe or unstable due to the force of water from the reservoir breach or failure.

The EA hold mapping showing what might happen if reservoirs fail. Developers and planners should check the [Long-Term Risk of Flooding \(gov.uk\)](https://www.gov.uk/government/consultations/long-term-risk-of-flooding) before using the reservoir data shown in this SFRA to make sure they are using the most up to date mapping.

The EA provide two flooding scenarios for the reservoir flood maps: a 'dry-day' and a 'wet-day'. The 'dry day' scenario shows the predicted flooding which would occur if the dam or reservoir fails when rivers are at normal levels. The 'wet day' scenario shows the predicted worsening of the flooding which would be expected if a river is already experiencing an extreme natural flood. It should be noted that these datasets give no indication of the likelihood or probability of reservoir flooding. The EA maps represent a credible worst-case scenario. In these circumstances it is the time to inundation, the depth of inundation, the duration of flooding and the velocity of flood flows that will be most influential.

The current mapping shows that there are 15 reservoirs located outside the borough with residual risk of flood extents impacting the study area (detailed in Table 4-2). There are no reservoirs located within the Tamworth study area. The reservoir locations are shown in Figure 4-5. The reservoir flood mapping for both the 'dry day' and 'wet day' scenarios in the study area has been provided in Appendix A: GeoPDFs.

In addition to the risk of inundation, those considering development in areas affected by breach events should also assess the potential hydraulic forces imposed by the rapid flood event and check that that the proposed infrastructure fabric can withstand the loads imposed on the structures by a breach event.

Section 8.4.3 provides further considerations for developing in the vicinity of reservoirs.

Table 4-2: Reservoirs located outside the borough but where the flood extents impact the borough.

Reservoir	National GR	Reservoir owner	Risk Category	Local Authority	Does reservoir impact study area in 'dry day' scenario?
Bartley	SP0050081100	Severn Trent Water	High-risk	Birmingham	Yes
Belfry	SP1760096600	TB Resort Operations Limited	High-risk	Warwickshire	Yes
Canwell Estate Reservoir	SK1540000500	Smith Brothers Farms Limited	Not high-risk	Staffordshire	No
Chasewater (Cannock Chase)	SK0360007600	Canal & River Trust	High-risk	Staffordshire	Yes
Earlwood Lakes - Engine Pool	SP1110074100	Canal & River Trust	High-risk	Warwickshire	Yes
Earlwood Lakes - Windmill Pool	SP1142073874	Canal & River Trust	High-risk	Warwickshire	Yes
Frankley Raw Water	SP0030080300	Severn Trent Water	High-risk	Birmingham	No
Geary's, Packington	SP2200082500	Packington Estate Enterprises Ltd	Not high-risk	Warwickshire	No
Great Pool, Packington	SP2300083800	Packington Estate Enterprises Ltd	High-risk	Warwickshire	No
Hall Pool, Packington	SP2200083800	Packington Estate Enterprises Ltd	Not high-risk	Warwickshire	No
Middleton Hall Lake	SP1905098250	Middleton Hall Trust	High-risk	Warwickshire	Yes

Reservoir	National GR	Reservoir owner	Risk Category	Local Authority	Does reservoir impact study area in 'dry day' scenario?
Minworth Curdworth	SP1825791630	Severn Trent Water	High-risk	Birmingham District	Yes
Pendigo Lake	SP1930083500	The National Exhibition Centre Ltd	High-risk	Solihull	No
Rotton Park	SP0430086800	Canal & River Trust	High-risk	Birmingham	Yes
Shustoke Lower	SP2280091300	Severn Trent Water	High-risk	Warwickshire	Yes
Whitacre	SP2135091150	Severn Trent Water	High-risk	Warwickshire	Yes




Figure 4-5: Reservoirs located in the borough with flood extents that impact the borough.

4.9 Flooding from canals

Canals are regulated waterbodies and are unlikely to flood unless there is a sudden failure of an embankment or a sudden ingress of water from a river in areas where they interact closely. Embankment failure can be caused by:

- Culvert collapse
- Overtopping
- Animal burrowing
- Subsidence/ sudden failure e.g. collapse of former mine workings
- Utility or development works close or encroaching onto the footings of a canal embankment

Flooding from a breach of a canal embankment is largely dictated by canal and ground levels, canal embankment construction, breach characteristics and the volume of water within the canal that can discharge into the lower lying areas behind the embankment. The volume of water released during a breach is dependent on the pound length (i.e. the distance between locks) and how quickly the operating authorities can react to prevent further water loss, for example by the fitting of stop boards to restrict the length of the canal that can empty through the breach, or repair of the breach. The Canal and River Trust monitor embankments at the highest risk of failure and have equipment in place to steam breaches in the highest risk locations.

There is one canal present in Tamworth, the Coventry Canal, which flows through the centre of the borough. Additionally, the Birmingham and Fazeley Canal is present along the western borough boundary but does not pass through the study area.

Data provided by the Canal and Rivers Trust suggests there have been no records of breaching or overtopping within the Tamworth borough.

4.10 Flood alerts and flood warnings

The EA is the lead organisation for providing warnings of river flooding. Flood Warnings are supplied via the Flood Warning System (FWS) service, to homes and business within Flood Zones 2 and 3. The EA [Sign up for Flood Warnings \(gov.uk\)](https://www.gov.uk/sign-up-for-flood-warnings) page provides further information on how to sign up for these warnings.

There are currently three Flood Alert Areas (FAA) and seven Flood Warning Areas (FWAs) covering the borough. Flood Alerts are issued when there is water out of bank for the first time anywhere in the catchment, signalling that 'flooding is possible', and therefore FAAs usually cover the majority of main river reaches.

Flood Warnings are issued to designated FWAs (i.e., properties within the extreme flood extent which are at risk of flooding), when the river level hits a certain threshold; this is correlated between the FWA and the gauge, with a lead time to warn that 'flooding is expected'.

4.11 Summary of flood risk in the borough

A table summarising all sources of flood risk to key settlements in the study area can be found in Appendix D. For this summary, the borough has been delineated into three sub-areas. These sub-areas are based on watercourse catchments and key settlements. The sub-areas are detailed below and presented in Figure 4-6:

- Sub-area 1 is located in the north-west of the Tamworth borough. It is mostly urban, with the exception of a stretch of land in the east, the Broad Meadow Local Nature Reserve, and the Tameside Nature Reserve in the south.
- Sub-area 2 covers the northeastern portion of the borough and has the largest expanse of rural land out of the three sub-areas, encompassing Tamworth railway station, the Derby-to-Birmingham Line runs north-south and the Trent Valley Line runs east-west. The north/northwest of this sub-area is largely rural, with built-up areas situated in the south and west.
- Sub-area 3 is the southern part of the borough and is the largest of the three sub-areas. It is mostly urban but has some green spaces along the Kettle Brook and in the south, such as Kettle Brook Nature Reserve and the land west of Dosthill. The Derby-to-Birmingham Line runs through this sub-area, and Coventry Canal flows along the northern boundary. Key areas include Hockley, Dosthill, Two Gates, Wilnecote, Belgrave, Glascote, Stonydelph, and parts of Amington in the north.




Figure 4-6 Sub-Areas used to divide Tamworth Borough and summarise flood risk

5 Impact of Climate Change

Climate change projections show an increased chance of warmer, wetter winters and hotter, drier summers with a higher likelihood of more frequent and intense rainfall. This is likely to make severe flooding happen more often.

The NPPF sets out that flood risk should be managed over the lifetime of a development, taking climate change into account. This section sets out how the impact of climate change should be considered.

5.1 Revised climate change guidance

The [Climate Change Act 2008 \(legislation.gov.uk\)](https://legislation.gov.uk) creates a legal requirement for the UK to put in place measures to adapt to climate change and to reduce carbon emissions by at least 80% below 1990 levels by 2050. This was updated in June 2019 under the [Climate Change Act 2008 \(2050 Target Amendment\) Order \(legislation.gov.uk\)](https://legislation.gov.uk) to a 100% reduction (or net zero) by 2050.

In 2018, the government published new UK Climate Projections (UKCP18). The EA used these projections to update their climate change guidance for new developments with regards to updated fluvial and rainfall allowances. The EA published updated climate change guidance for fluvial risk in July 2021 on how allowances for climate change should be included in both strategic and site-specific FRAs. The guidance adopts a risk-based approach considering the vulnerability of the development and considers risk allowances on a management catchment level, rather than a river basin level. The guidance was further updated in May 2022 to address the changes to the requirements for peak rainfall allowances.

5.1.1 Applying the Climate Change Guidance

Developers will need to undertake a detailed assessment of climate change as part of the planning application process when preparing FRAs. Developers should refer to [Flood Risk Assessments: Climate Change Allowances \(gov.uk\)](https://gov.uk) for the latest guidance.

To apply the appropriate climate change guidance to a site, the following information is required:

- The vulnerability of the development – see [Annex 3 in the NPPF \(gov.uk\)](https://gov.uk).
- The likely lifetime of the development – in general 75 years is used for commercial development and 100 for residential, but this needs to be confirmed for an FRA. For development that will have an anticipated lifetime significantly beyond 100 years a higher allowance is required.
- The Management Catchment (assigned by the EA) that the site is located in (The whole of Tamworth Borough is within the Tame, Anker, and Mease Management Catchment). The study area is located entirely within the Tame, Anker and Mease Management Catchment.

Developers should consider the following when deciding which allowances to use to address flood risk for a development or Local Plan allocation:

- Likely depth, speed, and extent of flooding for each allowance of climate change over time considering the allowances for the relevant epoch (2020s, 2050s and 2080s).
- The 'built in' resilience measures used, for example, raised floor levels.
- The capacity or space in the development to include additional resilience measures in the future, using a 'managed adaptive' approach.

If the site is just outside the indicative climate change extents in this SFRA, the impact of climate change should still be considered because the site may be affected should the more extreme climate change scenarios materialise.

Further guidance on site-specific FRAs can be found in Section 8.2.

5.2 Relevant allowances for the study area

Table 5-1 shows the updated peak river flow allowances that apply across the study area for fluvial flood risk in the Tame, Anker and Mease Management Catchment. These allowances supersede the previous allowances by River Basin District.

The range of allowances are based on percentiles which describe the proportion of possible scenarios that fall below an allowance level:

- The central allowance is based on the 50th percentile (exceeded by 50% of the projections in the range).
- The higher central allowance is based on the 70th percentile (exceeded by 30% of the projections in the range).
- The upper end allowance is based on the 95th percentile (exceeded by 5% of the projections in the range).

Table 5-1: Peak river flow allowances for the Tame, Anker and Mease Management Catchment.

Allowance category	Total potential change (%) anticipated for '2020s' (2015 to 2039)	Total potential change (%) anticipated for '2050s' (2040 to 2069)	Total potential change (%) anticipated for '2080s' (2070 to 2115)
Central	10	11	22
Higher central	15	17	30
Upper end	24	30	51

Table 5-2 shows the updated rainfall intensity allowances that apply across the study area for surface water flood risk in the Tame, Anker and Mease Management Catchment. These allowances supersede the previous country wide allowances. These allowances should be

used for site-specific applications and for surface water flood mapping in small catchments (less than 5km²) and urbanised drainage catchments.

Table 5-2: Peak rainfall intensity allowances for small and urban catchments for the Tame, Anker and Mease Management Catchment.

Allowance category	Total potential change (%) anticipated for '2050s' (2022 to 2060) 3.3% AEP	Total potential change (%) anticipated for '2050s' (2022 to 2060) 1% AEP	Total potential change (%) anticipated for '2070s' (2061 to 2125) 3.3% AEP	Total potential change (%) anticipated for '2070s' (2061 to 2125) 1% AEP
Upper end	35	40	35	40
Central	20	20	25	25

5.3 Representing climate change in the Level 1 SFRA

Two fluvial hydraulic models were received from the EA. These models were reviewed to determine their age, type of model, and the outputs available. A pragmatic approach was then taken to determine a methodology which aims to make best use of the available model data whilst balancing the LPU timescales and budgets. More detailed modelling of different climate change scenarios may need to be considered further if and when a Level 2 assessment is required or during a site-specific Flood Risk Assessment.

The sections below detail the approaches taken to consider climate change for fluvial, and surface water flooding within this SFRA. Further details on the available modelling are set out in Appendix B.

5.3.1 Fluvial climate change

5.3.1.1 3.3% AEP (Functional floodplain - Flood Zone 3b)

None of the EA hydraulic models provided for this SFRA currently have available outputs for 3.3% AEP or 3.3% AEP plus climate change events so a pragmatic approach has been used in agreement with the EA. Detailed hydraulic modelling may be needed to confirm the effects of climate change on the functional floodplain at the site-specific FRA stage.

While neither of the hydraulic models provided for this SFRA currently have outputs that represent the 3.3% AEP or 3.3% AEP plus climate change events, as part of NaFRA2 the EA have released 3.3% AEP plus climate change outputs for the New National Model (NNM) which has been used in this SFRA to represent this scenario. At site-specific FRA stage, more detailed hydraulic modelling may be required to further investigate the impact of climate change on the functional floodplain.

For Ordinary Watercourses where there is no national mapping available, the 1% AEP risk of surface water flooding dataset has been used as a proxy to infer risk.

5.3.1.2 1% AEP (Flood Zone 3a)

In the Tame, Anker and Mease Management Catchment, there has been minimal changes between the previous climate change uplifts (+20%, +30%, and +50%) for the Humber RBD and the current uplifts (+22%, +30%, and +51%) for the central, higher central, and upper end uplifts for the 2080s epoch. As fluvial climate change outputs released as part of NaFRA2 are only available for the Central allowance, the existing 1% AEP plus climate change outputs, uplifted as part of the previous Leicestershire and Leicester City Level 1 SFRA, have been used for River Anker model within this Management Catchment.

The Lower Tame (2023) model has not yet been included in NaFRA2, therefore in agreement with the EA, outputs from this model have been used in this SFRA in preference to NaFRA2 outputs. For the Lower Tame model, the Central climate change allowance was the only available climate change output for the 2080s epoch. In agreement with the EA, the Lower Tame model has been uplifted for the latest Higher Central climate change allowance for the 1% AEP event in the 2080s epoch for the Tame, Anker, and Mease Management Catchment (+30%).

For areas with no detailed hydraulic modelling, the NaFRA2 1% AEP plus climate change outline is used as an indicative climate change extent.

5.3.1.3 0.1% AEP (Flood Zone 2)

None of the EA hydraulic models provided currently have available outputs for 0.1% AEP plus climate change events. Uplifting existing models with climate change allowances for the 0.1% AEP event presents significant time and cost implications due to practical issues as most models are not built to run events of this magnitude, and often present instabilities and an inability to run. As such, 0.1% AEP plus climate change outputs from the EA's New National Model (NNM) available as part of NaFRA2 have been used to represent this scenario in this SFRA.

If development is proposed within close proximity of the 0.1% AEP event (Flood Zone 2) this risk should be considered further in a site-specific Flood Risk Assessment.

5.3.2 Surface water climate change

5.3.3 As no appropriate climate change uplifts to NaFRA2 surface water mapping have been released yet, The 0.1% AEP surface water extent can be used as an indication of surface water risk, and risk to smaller watercourses that are too small to be covered by the EA's Flood Zones. Impacts of climate change across the borough

This section explores which areas of the borough are most sensitive to increases in flood risk due to climate change. It should be noted that areas that are already at high risk will

also become at increasing risk in future and the frequency of flooding will increase in such areas.

It is recommended that the Council works with other RMAs to review the long-term sustainability of existing and new development in these areas when developing climate change plans and strategies for the study area.

5.3.4 Impact of climate change on fluvial flood risk

The sensitivity of an area to climate change can be analysed through comparison between present day design flood event extents and design flood events extents with modelled climate change uplifts applied. Due to the presence of formal flood defences across large parts of the study area, the defended climate change modelled flood extents have been compared with the defended 1% AEP flood extent. It should be noted that there is a residual risk should the defences breach or overtop. Further details on defences within the study area and residual risk can be found in Section 6.

Areas in the study area identified as most sensitive to fluvial impacts of climate change from defended modelled outputs are:

- Tamworth Castle Grounds and the area on the opposite side of the River Tame, comprising the Planet Walk and a number of commercial properties.
- The properties north of the River Anker, within and around the Anker Drive/Bolebridge Street roundabouts.
- The residential areas between Saxon Drive and Victoria Road, as well as the commercial properties along Bolebridge Street and by Tamworth Town substation.
- The residential areas in Coton Farm, including properties around: Osborne, Chartwell, Kentwell, Glyndebourne, Godolphin, Braham, and Browsholme.
- Parts of the rural land in the northeast of the Borough, including the properties situated north in close proximity of the River Anker.

Where no detailed modelling exists the 1% AEP flood extent (Flood Zone 3a) can be compared against the 1% AEP plus climate change outputs from the New National Model (NNM).

Areas in the study area identified as most sensitive to fluvial impacts of climate are:

- The residential area north of Dunstall Lane.
- The properties north of the weir at Oxbridge Weir, from Blackfriars Close to Mansfield Close.
- The properties that lie north of Arrington Road and west of Moor Lane, including Bolehall Manor Club.
- The SnowDome, the Tamworth Football Club car park, and the most northwestern row of properties on Tame Street.

5.3.5 Impacts of climate change on surface water flood risk

The 1% AEP surface water event with an upper climate change uplift can be compared to the present day 1% AEP extent for an indication of areas most sensitive to climate change.

While across the study area, a significant difference in surface water flood extents is observed, areas in the study area most sensitive to changes in surface water flood risk are typically in low lying, urban locations. In particular, the following areas are sensitive to increased surface water flooding due to climate change:

- Several roads and properties in Coton Farm and Lichfield Road Industrial Estate.
- Wigginton Park (mainly south and east), and parts of the surrounding residential areas. This includes the roads to the west located by the Trent Valley Line, and several streets to the east in Leyfield, such as Shelley Road and Masefield Drive.
- The commercial area located near the Jolly Sailor Roundabout.
- The residential neighbourhoods south of the A5, and west of Fazeley Road, near the border of the Borough.
- The area in the south of Kettlebrook, particularly south of Campion drive around Celandine, as well as several businesses east of Kettlebrook Road.
- The urban areas within and north of Anker Drive/Bolebridge Street roundabouts, including further north around Heath Street and Victoria Road.
- Several rural areas, such as the floodplains around the River Anker in the northeast and south of the River Tame in the northwest. Other areas include the Warwickshire Moor Local Nature Reserve, and the land along the Kettle Brook within the Anker Drive/Bolebridge Street roundabouts, as well as just north Borrowpit Lake.
- The residential area between the Coventry Canal and Brindley Drive, particularly affecting properties around Whitley Avenue, Selker Drive, Talland Avenue, and Stonehaven.
- Parts of Amington, mainly contained to roads, but affecting several properties, including between Turnberry and Lytham, and by the eastern border, including around Cheddleton Close and Boundary Drive.
- Tamworth Enterprise College, Stonydelph Primary School, Torc College and the athletics sports track.
- Several roads in Dosthill, particularly properties west of High Street and in the neighbourhood between Magnus and Hedging Lane.
- Parts of Hedging Lane Industrial Estate and Tame Valley Industrial Estate.
- Key transport infrastructure, including large parts of the A5 and along both the Trent Valley and Derby-to-Birmingham lines.
- Properties in the north of Belgrave, particularly around Hayle and Medway, as well as several residential streets on the opposite side of the A5, including much of the lands attached to Lakeside Primary School
- Several streets across Glascote, Glascote Heath, Stonydelph, Two Gates, and Hockley are also sensitive to increased surface water flooding, but the flood extents are mainly contained to roads.

5.3.6 Impacts of climate change on groundwater flood risk

There is no modelling data available to assess climate change impacts on groundwater. The assessment would depend on the flooding mechanism, historic evidence of known flooding and geological characteristics, for example prolonged rainfall in a chalk catchment. Flood risk could increase when groundwater is already high or emerged, causing additional overland flow paths or areas of still ponding.

A high likelihood of groundwater flooding may mean infiltration SuDS are not appropriate, and groundwater monitoring may be recommended.

5.3.7 Adapting to climate change

PPG: Climate Change (gov.uk) Paragraph 003 (Reference ID: 6-003-20140612) contains information and guidance for how to identify suitable mitigation and adaptation measures in the planning process to address the impacts of climate change. Paragraph 005 (Reference ID: 6-005-20140306) also provides considerations for the LPA on dealing with the uncertainty of climate risks and accounting for climate change in a realistic way within developments.

It is recommended that the climate change flood extents are compared with present day extents by the LPA when allocating sites, to understand how much additional risk there could be, where this risk is in the site, whether the increase is marginal or activates new flow paths, whether it affects access/ egress and how much land could still be developable overall.

6 Flood alleviation schemes and assets

This section provides a summary of existing flood alleviation schemes and assets in the borough. Planners should note the areas that are protected by defences where further work to understand the actual and residual flood risk through a Level 2 SFRA may be beneficial. Developers should consider the benefit they provide over the lifetime of a development in a site-specific FRA.

6.1 Asset management

RMAs hold databases of flood risk management and drainage assets according to their jurisdiction as follows:

- The EA holds a national database that is updated by local teams.
- The LLFA holds a database of significant local flood risk assets, required under Section 21 of the FWMA (2010).
- Highways Authorities hold databases of highways drainage assets, such as gullies and connecting pipes.
- Water Companies hold records of public surface water, foul and combined sewers, the records may also include information on culverted watercourses.
- The databases include assets RMAs directly maintain and third-party assets. The drainage network is extensive and will have been modified over time. It is unlikely that any RMA contains full information on the location, condition, and ownership of all the assets in their area. They take a prioritised approach to collecting asset information, which will continue to refine the understanding of flood risk over time.

Developers should collect the available asset information and undertake further survey as necessary to present an understanding of current flood risk and the existing drainage network in a site-specific FRA.

6.2 Standards of Protection

Flood defences are designed to give a specific Standard of Protection (SoP), reducing the risk of flooding to people and property in flood prone areas. For example, a flood defence with a 1% AEP SoP means that the flood risk in the defended area is reduced to at least a 1% chance of flooding in any given year.

Over time the actual SoP provided by the defence may decrease, for example due to deterioration in condition or increases in flood risk due to climate change. The understanding of SoP may also change over time as RMAs undertake more detailed surveys and flood modelling studies.

It should be noted that the EA's on-going hydraulic modelling programme may revise flood risk datasets and, therefore, the SoP offered by flood defences in the area may differ from those discussed in this report.

6.3 Maintenance

Different authorities have responsibilities relating to maintenance of flood risk assets, set out in Table 6-1. It is important that the authorities work in partnership to maintain flood risk assets and manage flood risk across the study area.

Table 6-1: Flood risk asset maintenance responsibilities.

Authority	Asset maintenance responsibilities
EA	Permissive powers to maintain and improve main rivers, ultimate responsibility for maintaining watercourses rests with the landowner.
Local Authorities	Permissive powers to maintain and improve ordinary watercourses, ultimate responsibility for maintaining watercourses rests with the landowner.
LLFA	Permissive powers, limited resources are prioritised and targeted to where they can have the greatest effect
Highways Authorities	Duty to maintain public roads, making sure they are safe, passable, and the impacts of severe weather have been considered. Responsible for maintaining sections of watercourses where they are crossed by highways.
Water Companies	Duty to effectually drain their area. What this means in practise is that assets are maintained to common standards and improvements are prioritised for the parts of the network that do not meet this standard e.g., where there is frequent sewer flooding.
Riparian Owners	Responsible for the protection of their properties from flooding as well as other management activities, for example by maintaining riverbeds/banks, controlling invasive species, and allowing the flow of water to pass without obstruction.

There is potential for the risk of flooding to increase in areas where flood alleviation measures are not maintained regularly. Breaches in raised flood defences are most likely to occur where the condition of a flood defence has degraded over time. Drainage networks in urban areas can also frequently become blocked with debris and this can lead to blockages at culverts or bridges.

Developers should not assume that any defence, asset, or watercourse is being or will continue to be maintained throughout the lifetime of a development. They should contact the relevant RMA about current and likely future maintenance arrangements and make future users of the development aware of their obligations to maintain watercourses.

Formal structural defences are given a rating based on a grading system for their condition. A summary of the grading system used by the EA for condition is provided in Table 6-2.

Table 6-2: Grading system used by the EA to assess flood defence condition.

Grade	Rating	Description
1	Very good	Cosmetic defects that will have no effect on performance.
2	Good	Minor defects that will not reduce the overall performance of the asset.
3	Fair	Defects that could reduce the performance of the asset.
4	Poor	Defects that would significantly reduce the performance of the asset. Further investigation required.
5	Very poor	Severe defects resulting in complete performance failure.

Source: Condition Assessment Manual – EA 2006

6.4 Major flood risk management assets in the borough

The EA retired the Flood Map for Planning ‘Areas Benefiting from Defences’ (ABD) dataset in December 2022. This dataset will no longer be available on online mapping. Instead, a developer can enter an address into the [EA Flood Map for Planning \(gov.uk\)](https://www.gov.uk/government/organisations/environmental-agency/about/flood-map-for-planning) to get information about their specific site and request flood risk assessment data for planning (also known as Product 4).

The EA ‘AIMS’ (Asset Information Management System) flood defence dataset gives further information on flood defence assets within the study area. Table 6-3 details the locations which benefit from formal flood defences within the ‘AIMS’ dataset. There is also natural high ground along sections of the River Tame and River Anker, as well as engineered high ground along the Fazeley Brook. For further details of specific defences, developers should refer to the [AIMS Spatial Flood Defences dataset \(gov.uk\)](https://www.gov.uk/government/organisations/environmental-agency/about/flood-map-for-planning), which can be downloaded from the EA website and viewed in Appendix A GeoPDF Mapping.

Table 6-3: Locations shown in the EA 'AIMS' data set.

Watercourse	Location	Type	Design SoP (AEP)	Condition Rating (1-5)	Ownership
River Tame	Channel under Tame Drive, Tamworth	Bridge Abutment	0	Unknown	Unknown
Fazeley Brook	Fazeley Rd floodbank	Embankment	1%	3	Unknown
Fazeley Brook	Floodbank along Tamworth Rd, Fazeley	Embankment	1%	Unknown	Unknown
Fazeley Brook	Floodbank along Fazeley Rd	Embankment	1%	3	Unknown
Fazeley Brook	Floodbank round Meadow Bank, Fazeley	Embankment	1%	4	Unknown
Fazeley Brook	Floodbank around Willowbank, Fazeley	Embankment	1%	4	Unknown
River Tame	Floodbank along Fazeley Rd	Embankment	1%	3	Unknown
River Tame	High ground through pump station along Dunstall Ln should be high ground	Embankment	1%	2	Local Authority
River Tame	Floodbank along Dunstall Lane	Embankment	1%	3	Unknown
Fazeley Brook	Bonehill Lane floodbank	Embankment	1%	3	Unknown
River Tame	Floodbank along Lichfield Rd, Broad Meadow	Embankment	1%	2	Unknown
River Tame	Floodbank along Lichfield Rd, Broad Meadow	Embankment	1%	3	Unknown
River Tame	Floodbank u/s of Tame Drive, Broad Meadow	Embankment	1%	3	Unknown
River Tame	Moat House Flood Embankment	Embankment	1%	3	Unknown

Watercourse	Location	Type	Design SoP (AEP)	Condition Rating (1-5)	Ownership
River Tame	Floodbank along Dunstall Lane	Embankment	1%	3	Unknown
River Tame	Floodbank by Hopwas bridge	Embankment	0.5%	3	Unknown
River Tame	Coton Lane, Tamworth	Embankment	0.5%	5	Unknown
River Tame	Embankment	Embankment	0	3	Environment Agency
River Tame	Flood Wall at Ventura Park, Fazeley	Wall	1%	3	Private individual, Company or Charity
Fazeley Brook	Shed floodwall	Wall	0	3	Environment Agency
River Tame	Sunset Close floodwall	Wall	1%	3	Private individual, Company or Charity
Fazeley Brook	Jolly Sailor Flood Wall	Wall	1%	3	Private individual, Company or Charity
River Tame	Floodwall along Lichfield Rd, Tamworth	Wall	1%	3	Private individual, Company or Charity
River Tame	Floodwall by Sunset Close, Tamworth	Wall	1%	3	Private individual, Company or Charity
River Tame	Floodwall by Sunset Close, Tamworth	Wall	1%	2	Private individual, Company or Charity
Fazeley Brook	Floodwall by Fazeley Rd, Tamworth	Wall	1%	3	Private individual, Company or Charity
River Tame	Floodwall along Lichfield Road, Coton	Wall	0.5%	3	Private individual, Company or Charity

Watercourse	Location	Type	Design SoP (AEP)	Condition Rating (1-5)	Ownership
River Tame	Floodbank by Fox Pub, Coton	Wall	0.5%	2	Private individual, Company or Charity
River Tame	Floodwall Hopwas Bridge	Wall	0.5%	2	Private individual, Company or Charity
River Tame	Floodwall and access ramp on Lichfield Rd, Coton	Wall	0.5%	2	Private individual, Company or Charity
River Tame	Floodwall by Fox roundabout, Lichfield Rd	Wall	0.5%	2	Private individual, Company or Charity
River Tame	Floodwall around Coton House, Lichfield Rd, Coton	Wall	0.5%	3	Private individual, Company or Charity
River Tame	Floodwall around Coton House Farm, Lichfield Rd	Wall	0.5%	3	Private individual, Company or Charity

In addition to the flood risk management assets included in the EA's AIMS dataset, listed above, SCC, the LLFA covering the Tamworth Borough provided a record of their flood risk management assets in the borough. The record includes details of 164 assets, including balancing ponds, culverts, pumping stations, trash screens and headwalls.

6.5 Existing and future flood alleviation schemes

A flood alleviation scheme on the River Tame and River Anker is currently being planned in Tamworth. At the time of this SFRA's publication, the scheme is at the first stage of the business case process. The plans include the rebuilding of existing defences to increase standard of protection. Current timescales would aim for construction to start around 2028/2029.

6.6 Actual and residual flood risk

A Level 2 SFRA (for strategic allocations) or developer site-specific FRA will need to consider the actual and residual flood risk due to the presence of flood and drainage assets

in greater detail (although it should be noted that Flood Zone 3b is based on the actual flood risk).

6.6.1 Actual flood risk

This is the risk to the site considering existing flood mitigation measures and any planned to be provided through new development. Note that it is not likely to be acceptable to allocate developments in existing undefended areas on the basis that they will be protected by developer works, unless it can be demonstrated there is a wider community benefit.

The assessment of the actual risk should consider that:

- The level of protection afforded by existing defences might be less than the appropriate standards and hence may need to be improved if further growth is contemplated.
- The flood risk management policy for the defences will provide information on the level of future commitment to maintain existing standards of protection. If there is a conflict between the proposed level of commitment and the future needs to support growth, then it will be a priority for this to be reviewed.
- The standard of safety must be maintained for the intended lifetime of the development. Over time the effects of climate change will erode the present-day SoP afforded by defences and so commitment is needed to invest in the maintenance and upgrade of defences if the present-day levels of protection are to be maintained and where necessary, land secured and safe-guarded that is required for affordable future flood risk management measures.
- By understanding the depth, velocity, speed of onset and rate of rise of floodwater it is possible to assess the level of hazard posed by flood events from the respective sources.

6.6.2 Residual risk

Residual risk is the risk that remains after the effects of flood risk infrastructure have been considered. It is important that these risks are quantified to confirm that the consequences can be safely managed. The residual risk can be:

- The effects of a larger flood than defences were designed to alleviate. This can cause overtopping of flood banks, failure of flood gates to cope with the level of flow or failure of pumping systems to cope with the incoming amount of water.
- Failure of the defences or flood risk management measures, such as breaches in embankments or walls, failure of flood gates to open or close or failure of pumping stations.

This SFRA does not assess the probability of failure other than noting that such events are very rare. However, in accordance with the NPPF, all sources of flooding need to be considered. If a breach or overtopping event were to occur, then the consequences to people and property could be high. It is the responsibility of the developer to fully assess

flood risk, propose measures to mitigate it and demonstrate that any residual risks can be safely managed.

The risk from overtopping of defences is based on the relative heights of property or defence, the distance from the defence level and the height of water above the crest level of the defence. The [Defra and EA Flood Risks to People guidance document \(gov.uk\)](https://www.gov.uk/guidance/defra-and-ea-flood-risks-to-people) provides standard flood hazard ratings based on the distance from the defence and the level of overtopping. Any sites located next to defences or perched ponds/ reservoirs, may need overtopping modelling or assessments at the site-specific FRA stage, and climate change needs to be taken in to account.

A breach of a defence occurs when there is a failure in the structure and a subsequent ingress of flood water. Flood flows from breach events can be associated with significant depths and flow velocities in the immediate vicinity of the breach location and so FRAs must include assessment of the hazards that might be present so that the safety of people and structural stability of properties and infrastructure can be appropriately considered. Whilst the area in the immediate vicinity of a breach can be subject to high flows, the whole flood risk area associated with a breach must also be considered as there may be areas remote from the breach that might, due to topography, involve increased depth hazards.

Considerations include the location of a breach, when it would occur and for how long, the depth of the breach (toe level), the loadings on the defence and the potential for multiple breaches. There are currently no national standards for breach assessments and there are various ways of assessing breaches using hydraulic modelling. Work is currently being undertaken by the EA to collate and standardise these methodologies. It is recommended that the EA are consulted if a development site is located near to a flood defence, to understand the level of assessment required and to agree the approach for the breach assessment.

Guidance on site-specific FRAs can be found in Section 8.2.

7 Cumulative impact of development and strategic solutions

7.1 Introduction

The cumulative impact of development should be considered at both the Local Plan making stage and the planning application and development design stages. Paragraph 166 of the National Planning Policy Framework (NPPF, 2024) states:

'Strategic policies should be informed by a strategic flood risk assessment and should manage flood risk from all sources. They should consider cumulative impacts in, or affecting, local areas susceptible to flooding, and take account of advice from the Environment Agency and other relevant flood risk management authorities, such as lead local flood authorities and internal drainage boards.'

When allocating land for development, consideration should be given to the potential cumulative impact of the loss of floodplain storage volume from any source, as well as the impact of increased flows on flood risk downstream. Whilst the loss of storage for individual developments may only have a minimal impact on flood risk, the cumulative effect of multiple developments may be more severe. Similarly, the effect of the loss of surface water flow paths / exceedance paths from sewers, surface water ponding and infiltration can also give rise to cumulative effects and potentially exacerbate flood risk. There are also risks of development causing modified flow regimes from sites creating an alignment in peak flows in downstream watercourses and resulting in greater flood risk as a result of the development.

All developments are required to comply with the NPPF and demonstrate they will not increase flood risk elsewhere. Therefore, providing developments comply with the latest guidance and legislation relating to flood risk and sustainable drainage, and appropriate consideration is given to flow paths and storage, proposals should normally not increase flood risk downstream.

Land that is required for current and future flood risk management will be safeguarded from development. Where development lies adjacent to or benefits from an existing or future flood defence, the developer will be expected to contribute to the cost of delivery and/or maintenance of that scheme. Financial contributions are also sought after to contribute towards flood warning services (or related infrastructure) where a development is reliant on such for safe development.

Local planning policies can also be used to identify areas where the potential for development to increase flood risk is highest and identify opportunities for such new development to positively contribute to decreases in flood risk downstream.

7.2 Methodology

For the Cumulative Impact Assessment (CIA), Tamworth Borough was assessed at a catchment level using the Water Framework Directive (WFD) catchments, with these

catchments shown in Figure 7-1. There are a total of 5 WFD catchments which fall within the borough to some extent.

There are four stages to the Level 1 CIA:

- Assess sensitivity to increases in fluvial and surface water flood risk.
 - This was assessed by calculating the change in the building area shown to flood from the 1% AEP to the 0.1% AEP events for fluvial and surface water flooding respectively, given as a percentage of the total building area in the catchment.
 - The OS Open Zoomstack Local Buildings layer was used to identify the built area within the catchments as this is an open data source which provides full coverage of the borough and cross boundary catchments.
- Identify historic flooding incidents.
 - Identify the total number of historic flooding incidents within each catchment.
 - The historic data was represented as point data, where each point represents a location where it is known there has been at least one flood event (however, the nature and scale of these flood events varies significantly).
 - Historic data was only available for Tamworth Borough and was excluded for the 'Langley Brook from Middleton Hall Catch to R Tame' and 'Black-Bourne Bk from source (confluence) to R Tame catchments' as only 0.5% and 0.1% respectively of these catchments fall within Tamworth Borough.
- Assess the catchments with the highest degree of proposed new development.
 - This was assessed by calculating the area of proposed new development within each catchment, expressed as a percentage of the total catchment area.
 - At this stage the whole area of each development was considered, with no land use assumptions for the development areas.
- Identify the most sensitive catchments to increased risk.
 - Discussion of each catchment
 - Policy recommendations for developments in higher risk catchments.

Table 7-1 summarises the datasets used within the Tamworth CIA.

The final results of this assessment gave a relative sensitivity to increased risk for each metric, for each catchment within the study area. The rating of each catchment in each of these assessments was combined to give a relative overall assessment of risk.

Table 7-1 Datasets used in the Broadscale CIA

Dataset	Coverage	Sources of Data	Use of Data
Catchment boundaries	Tamworth Borough and neighbouring authorities	Water Framework Directive Catchments	Assessment of susceptibility to cumulative impacts of development by catchment

Dataset	Coverage	Sources of Data	Use of Data
OS Open Zoomstack Local Buildings	Tamworth Borough and neighbouring authorities	Ordnance Survey (Open Source)	Built area for the assessment of flood risk
Risk of Flooding from Surface Water	Tamworth Borough and neighbouring authorities	EA	Assessing the built area at risk of surface water flooding within each catchment
Fluvial Flood Zones 2 and 3a	Tamworth Borough and neighbouring authorities	EA Flood Map for Planning	Assessing the built area at risk of fluvial flooding within each catchment
Future development areas (recently built out sites/sites under construction/sites with planning permission/previously allocated sites/currently allocated sites)	Tamworth Borough and neighbouring authorities	Tamworth Borough and neighbouring authorities	Assessing the impact of proposed future development on risk of flooding




Figure 7-1 WFD Catchments across Tamworth Borough.

7.2.1 Ranking the results

While results from each of the three assessments for each catchment have been discussed relative to one another in this CIA, catchments have not been assigned an overall ranking and score. Assigning an overall ranking to catchments was not deemed appropriate in this assessment given the small number of WFD catchments intersecting Tamworth Borough.

There is currently no national guidance available for assessing the cumulative impacts of development. The analysis undertaken provides a relative assessment of the catchments within Tamworth Borough and is not comparable across other boroughs/districts.

7.2.2 Assumptions

The assumptions made when conducting the CIA are shown in Table 7-2.

Table 7-2 Assumptions made in CIA methodology

Assessment aspect	Details of limitation in method	Justification of method used
Fluvial flood risk	Used the Flood Map for Planning Flood Zone 2 as an indicative estimate of the impacts of climate change across the district.	Although detailed climate change modelling was available for some watercourses, the broader Flood Map for Planning covers the entire area of the catchments both within and outside the district and therefore provided a consistent approach for this high-level assessment.
Surface water flood risk	Used the 0.1% AEP extent from the Risk of Flooding from Surface Water Map as an indicative estimate of the impacts of climate change across the study area.	Although the Risk of Flooding from Surface Water Map was uplifted for climate change as part of this study, the uplifts were only applied to the study area, the Risk of Flooding from Surface Water Map covers the entire area of the catchments both within and outside the study area and therefore provided a consistent approach for this high-level assessment.
Historic Flooding Incidents	Only flooding incidents recorded that could be georeferenced to produce GIS files were used. Each point or line feature represents a location where it is known there has been at least one flood incident. The severity of the historic flooding event relating to the point/line	GIS data sources provided the most accurate results possible for the location of historic flooding incidents across the borough.

Assessment aspect	Details of limitation in method	Justification of method used
	feature has not been considered, just the total number of points within each catchment where there has been a flood incident. it is important to note that not all incidences of historic flooding will have been recorded by the LLFA.	
Historic Flooding Incidents	Historic data provided by Staffordshire County Council only covered Tamworth Borough and therefore does not provide data across some of the larger cross-boundary catchments.	Best available historic data has been used. To reduce any impacts of the limited data coverage, the historic assessment was not included for the two catchments with a significantly lower percentage of their area in Tamworth Borough within the overall ranking as the count is likely to be a considerable underestimate for these catchments.
Development	Have assumed all promoted sites provided are taken forward to development. Have not considered whether sites are greenfield or brownfield sites (with brownfield regeneration having the potential to reduce flood risk) or the proposed allocation type and land use of the site.	This is a reasonable worst-case scenario as we do not have further information to inform which sites are most likely to go forward to development.

7.3 Catchment Level Assessment

7.3.1 River Tame from River Anker to River Trent

Catchment overview

The River Tame from River Anker to River Trent catchment intersects Tamworth Borough in the northwest, extending into Lichfield District, the local authority area that the catchment is mostly located within. Within Tamworth Borough, the catchment covers the Leyfields, Town Centre and Coton Farm areas of Tamworth, downstream of the Tame-Anker confluence. While this area of the catchment is urbanised, the rest of the catchment, downstream of Tamworth is largely rural, aside from an area of Fradley.

At the upstream end of the catchment, the River Anker joins the River Tame near Tamworth town centre. From here, the River Tame splits in two. Broad Meadow Local Nature Reserve is located on the island between the River Tame and its flood relief channel. The River Tame then continues to flow north out of Tamworth Borough through a largely rural area to its confluence with the River Trent near Alrewas. Other smaller watercourses in the catchment include More Brook, which flows from the east of Lichfield, joining the River Tame to the south of Sittles Airfield.

Fluvial flood risk

Fluvial flood risk within the catchment follows the path of the River Tame, with flood extents also along the path of the rural More Brook, outside of Tamworth. The broadscale assessment identified fluvial flood risk in this catchment as relatively high due to the percentage of developed area shown to be sensitive to increases in fluvial flood risk. Within the catchment, the areas most sensitive to increases in fluvial flooding are in the west of the Coton Farm area of Tamworth immediately downstream of Broad Meadow Nature Reserve and the area to the south of the flood relief channel.

Surface water flood risk

Surface water flood risk is distributed widely along roads through the urban areas in the upstream end of the catchment in Tamworth. Elsewhere in the catchment, in the rural areas, surface water flow paths are distributed across natural topographic lows and channels. The broadscale assessment shows that the catchment has medium sensitivity to increases in surface water flooding in future. Within the catchment, receptors at risk from surface water flooding are concentrated in Tamworth Borough, particularly around the Lichfield Road Industrial Estate and from Clifton Avenue to Elizabeth Drive, Leyfields, it is therefore particularly important that development does not increase runoff and contribute to the existing known surface water issues and that careful consideration is given to proposals that affect the natural storage and flow of surface water.

Historic flooding

Within Staffordshire County Council's flood incident record, there are 27 events in Tamworth and within this catchment, the second highest of the five catchments. Reports of flooding as recorded in the questionnaire dataset are clustered around the Lichfield Road Industrial Estate, while SCCs flooding hotspots record identifies locations distributed throughout the catchment.

Development

This catchment has the second highest area of potential development sites identified in TBC's Strategic Housing and Land Availability Assessment (SHLAA). As this catchment is located downstream of all the other catchments intersecting Tamworth Borough, it is important that opportunities to utilise techniques such oversized SuDS to reduce surface water flows which are generally channelled towards the River Tame in this catchment are realised, and that development in these other catchments does not increase downstream flood risk in Lichfield District. As this catchment is located downstream of all other

catchments intersecting Tamworth, it is important that development in the upstream catchments achieves betterment in order to reduce risk of flooding in this catchment.

7.3.2 River Tame from River Blythe to River Anker

Catchment overview

The River Tame from River Blythe to River Anker catchment is located immediately upstream of the River Tame from River Anker to River Trent catchment. The catchment intersects Tamworth Borough in the southwest, covering areas including Dosthill and Two Gates. Outside of Tamworth Borough, the upstream end of the catchment extends from Coleshill Industrial Estate, downstream the Tame-Anker confluence, encompassing villages such as Whitacre Heath, Lea Marston, Marston and Kingsbury, located in North Warwickshire District.

At the upstream end of the catchment, the River Blythe and River Bourne join the River Tame near Ladywalk Nature Reserve. From here, the River Tame flows north, through purification lakes at Lea Marston and then to the west of Kingsbury, through Kingsbury Water Park, to the Tamworth Borough boundary.

Fluvial flood risk

Fluvial flood risk in the catchment follows the path of the River Tame, Flood Zone 3 covers a large extent, encompassing the village of Whitacre Heath. From here, flood extents from the River Tame largely match that of the Kingsbury Water Park and Middleton Lakes Reserve, generally not affecting urban areas until the River Tame enters Tamworth Borough. Within Tamworth Borough, receptors are at risk of fluvial flooding in the north of Fazeley. In the broadscale assessment, this catchment was identified as having medium sensitivity to increases in fluvial flooding.

Surface water flood risk

Given the suburban/rural mixed nature of the catchment, surface water flood risk is distributed widely across natural topographic depressions and channels as well as urban areas. The broadscale assessment shows that although the rural nature of the catchment limits the number of receptors at risk of surface water flooding, the catchment is highly sensitive to increases in surface water flooding. Areas most at risk include, from Highcliffe Road to the River Tame, along High Street, Dosthill, and areas around Tame Retail and Trade Park. It is therefore particularly important that development does not increase runoff and contribute to the existing known surface water issues and that careful consideration is given to proposals that affect the natural storage and flow of surface water.

Historic flooding

Within SCC's flood incident record, there are 12 events in Tamworth and within this catchment, the third highest of the five catchments. While no reports of flooding have been recorded in the questionnaire dataset for this area, SCCs flooding hotspots record identifies locations distributed throughout the area of Tamworth intersecting the catchment.

Development

Within this catchment there are a number of large greenfield sites identified in TBC's SHLAA. Given the potential to impact flood risk in the catchment immediately downstream on the River Tame, NFM techniques and oversized SuDS could be utilised to reduce the surface water flows channelled into the River Tame.

7.3.3 River Anker from River Sence to River Tame

Catchment overview

The River Anker from River Sence to River Tame intersects the largest percentage of Tamworth Borough of each WFD catchment, covering the west and centre of the borough. Within Tamworth, this area is largely urban, aside from an area of the River Anker's floodplain to the north of the borough. Other urban areas elsewhere within the catchment include the north of Atherstone, Grendon, Dordon and Polesworth. Aside from these areas, the upstream end of the catchment is largely rural.

At the upstream end of the catchment, the River Sence joins the River Anker to the north of Atherstone. The River Anker then flows west to its confluence with an unnamed tributary originating from Twycross in the far northeast of the catchment. From here, the Anker continues to flow east, through Polesworth and into Tamworth Borough, joining the River Tame near Tamworth town centre. Kettle Brook is another watercourse within this catchment, originating near the eastern boundary of Tamworth Borough and flowing west through Tamworth, towards the Tame Anker confluence.

Fluvial flood risk

The fluvial flood risk within the catchment follows the path of the River Anker, along the main upstream drainage channels and then along the main channel through the catchment. Fluvial flood risk in the catchment is generally lower in comparison to the catchments previously discussed, due to less development on the floodplain. The broadscale assessment shows that the catchment also has a lower sensitivity to increases in fluvial flooding.

Surface water flood risk

Surface water flood risk is distributed widely along roads through the urban areas in the downstream end of the catchment covering the west of Tamworth, including multiple surface water flow paths channelling surface water into the Tame and Anker. Elsewhere in the catchment, in the rural areas, surface water flow paths are distributed across natural topographic lows and channels. The broadscale assessment shows that the catchment has high sensitivity to increases in surface water flooding. Within the catchment, receptors at risk from surface water flooding are concentrated in Tamworth Borough, with surface water flowing in the direction of the rivers Tame and Anker. Major surface water flow paths present in the catchment include, from Glascote to the Trent Valley Line rail embankment and from Stonydelph Primary School to the A5 road, and from Offa Drive to the River Anker, east of Tamworth Town Centre. It is therefore particularly important that development does not increase runoff and contribute to flood risk downstream, existing

known surface water issues and that careful consideration is given to proposals that affect the natural storage and flow of surface water.

Historic flooding

SCC's historic flooding record shows this catchment to have the highest number of recorded historic flood incidents, with a total of 34 incidents recorded, comprised of 4 questionnaire dataset records and 30 hotspot records.

Development

This catchment has the highest area of potential development sites identified in TBC's SHLAA of all WFD catchments. Additionally, upstream of Tamworth in this catchment, North Warwickshire District have a number of large housing allocation sites. A number of potential development sites within and outside of Tamworth Borough are located on surface water flow paths and have the potential to increase flood risk downstream. As a result of this, it is important that opportunities to implement techniques such as oversized SuDS on these sites to provide betterment. Partnership working in this catchment is also key to ensure that any upstream development in North Warwickshire does not have negative impacts downstream in Tamworth.

7.3.4 Langley Brook from Middleton Hall Catchment to River Tame

This catchment is largely rural, aside from Drayton Bassett in the north and contains ordinary watercourses, flowing from west to east. Only a small (0.5% of the catchment area) downstream area of the catchment intersects Tamworth Borough.

As the catchment is mostly rural, fluvial and surface water flood risk are both considered low in comparison to other WFD catchments. While no planned growth from Tamworth or neighbouring authorities has been identified in this catchment, if development were to occur in this catchment, it is important that this would not exacerbate downstream flood risk in the downstream Tame catchment.

7.3.5 Black-Bourne Brook from source (confluence) to River Tame

This catchment is also largely rural, however, intersects the west of Fazeley at its downstream end. Only a small percentage (0.1%) of the catchment intersects Tamworth Borough at this downstream end, similar to the Langley Brook catchment.

Within the catchment, downstream areas of Fazeley are at risk from fluvial flooding from Black Brook and Bourne Brook. Additionally, in the broadscale assessment the catchment was shown to have medium sensitivity to increases in surface water flooding. While no sites have been identified in this catchment under TBC's SHLAA, three of Lichfield's housing allocations are within the catchment, upstream of Tamworth. As watercourses in this catchment are tributaries of the River Tame and the catchment's topography generally channels surface water towards the Tame catchment, implementation of SuDS techniques on these sites could benefit downstream locations in Tamworth.

7.4 Natural Flood Management (NFM)

Natural Flood Management (NFM) is used to protect, restore, and re-naturalise the function of catchments and rivers to reduce flood risk. A wide range of techniques can be used that aim to reduce flooding by working with natural features and processes in order to store or slow down flood waters before they can damage flood risk receptors (e.g., people, property, infrastructure, etc.).

Techniques and measures, which could be applied in the study area include:

- Creation of Offline Storage Areas
- Re-meandering streams (creation of new meandering courses or reconnecting cut-off meanders to slow the flow of the river)
- Targeted woodland planting
- Reconnection and restoration of functional floodplains
- Restoration of rivers and removal of redundant structures, i.e. weirs and sluices no longer used or needed
- Installation or retainment of large woody material in river channels
- Improvements in management of soil and land use
- Creation of rural and urban SuDS

To maximise the benefits of NFM, it is important that land which is likely to be needed for NFM is protected by safeguarding land for future flood risk management infrastructure. This is particularly important for infrastructure that reduces the risk of flooding to large amounts of existing development, or where options for managing risk in other ways are limited to achieve multiple benefits for flood risk and the environment.

It is important to recognise the value of maintenance or restoration of natural riparian zones, such as grasslands, which protect the soils from erosion and ‘natural’ meadows which can tolerate flood inundation. The use of Green Infrastructure throughout river corridors can also play a vital role in enhancing the river environment as well as safeguarding land from future development, protecting people and buildings from flooding and reducing flood risk downstream.

Tamworth is a largely urban borough, potentially limiting opportunity for NFM implementation, therefore it is important that TBC work closely with upstream authorities, particularly North Warwickshire District Council to identify and capitalise on NFM opportunities. Given the significance of surface water flood risk catchments, outlined in the broadscale CIA, and the urban nature of the borough, SuDS implementation is particularly important. Details of guidance and considerations for SuDS are outlined in Section 9 of the report.

The EA published an [evidence base \(gov.uk\)](https://www.gov.uk/government/uploads/system/uploads/attachment_data/file/614442/evidence_base_for_working_with_natural_processes_to_reduce_flood_risk.pdf) for working with natural processes to reduce flood risk to support the implementation of NFM, with maps showing locations with the potential for NFM measures. These maps are intended to be used alongside the evidence directory to help practitioners think about the types of measure that may work in a catchment and the best places in which to locate them.

The EA, together with Warwickshire Wildlife Trust and Tame Valley Wetlands Landscape Partnership, are currently leading the Tame Valley NFM project which involves the creation and restoration of wetlands in the Tame catchment. The project aims to provide multiple environments for wildlife and increase floodwater storage. More information can be found on JBA's Natural Processes Interactive Map.

Other websites that provide further information about ongoing NFM schemes and community works include [The Flood Hub \(thefloodhub.co.uk\)](https://thefloodhub.co.uk) and the [Rivers Trust NFM National Map \(therivertrust.hub.arcgis.com\)](https://therivertrust.hub.arcgis.com).

7.4.1 Opportunities and projects in and/or affecting the borough

7.4.1.1 Catchment Based Approach (CaBA)

The [Catchment Based Approach \(CaBA\) \(catchmentbasedapproach.org\)](https://catchmentbasedapproach.org) was introduced by the Government to establish catchment partnerships throughout England to jointly deliver improved water quality and reduce flood risk, directly supporting achievement of many of the targets set out within the Government's 25-year Environment Plan. CaBA partnerships are actively working in all 100+ river catchments across England and cross-border with Wales.

The Tame, Anker and Mease Catchment Partnership, hosted by Severn Trent Water, covers Tamworth Borough. Their vision is 'to protect and improve the quality, diversity, and resilience of the water environment within the Tame, Anker and Mease catchment for the benefit of people and wildlife'. Actions that the Partnership are working to meet are set out in the Action Management Plan 2020 - 2025 (catchmentbasedapproach.org).

8 Flood risk management requirements for developers

This section provides guidance on site-specific FRAs. These are carried out by (or on behalf of) developers to assess flood risk to and from a site. They are submitted with Planning Applications and should demonstrate how flood risk will be managed over the development's lifetime, considering climate change and vulnerability of users.

The report provides a strategic assessment of flood risk within the study area. Prior to any construction or development, site-specific assessments will need to be undertaken so all forms of flood risk, the actual and residual risk and SoP and safety at a site are considered in more detail. Developers should, where required, undertake more detailed hydrological and hydraulic assessments of watercourses to verify flood extents (including latest climate change allowances), to inform the sequential approach to developing within the site and prove, if required, whether the exception test can be satisfied.

A detailed FRA may show that a site, windfall or other, is not appropriate for development of a particular vulnerability or even at all. The sequential and exception tests in the NPPF apply to all developments and an FRA should not be seen as an alternative to proving these tests have been met.

8.1 Principles for new development

8.1.1 Apply the sequential and exception tests.

Developers should refer to Section 3 for more information on how to consider the sequential and exception tests. For allocated sites, the Councils should use the information in this SFRA to apply the Sequential test. For windfall sites a developer must undertake the sequential test, which includes considering reasonable alternative sites at lower flood risk. Only if it passes the sequential test should the exception test then be applied if required.

Where planning applications come forward on sites allocated in the development plan through the sequential test, applicants need not apply the sequential test again. However, the exception test will need to be applied as proposals at the application stage will need to demonstrate flood risk is not increased elsewhere and is safe.

Developers should also apply the sequential approach to locating development within the site. The following questions should be considered:

- can risk be avoided through substituting less vulnerable uses or by amending the site layout?
- can it be demonstrated that less vulnerable uses for the site have been considered and reasonably discounted? and
- can the site layout be varied to reduce the number of people, the flood risk vulnerability or the building units located in higher risk parts of the site?

8.1.2 Consult with statutory and non-statutory consultees at an early stage to understand their requirements.

Developers should consult with the EA, SCC as LLFA and the relevant sewerage undertaker at an early stage to discuss flood risk including requirements for site-specific FRAs, detailed hydraulic modelling and foul and surface water drainage assessment and design. It should be noted that some of these consultees may need to charge for advice requested by developers or landowners.

8.1.3 Consider the risk from all sources of flooding and that they are using the most up to date flood risk data and guidance.

The SFRA can be used by developers to scope out what further detailed work is likely to be needed to inform a site-specific FRA. At a site level, developers will need to check before commencing on a more detailed FRA that they are using the latest available datasets. Developers should apply the most up-to-date climate change guidance (last updated in May 2022) and consider climate change adaptation measures. Site-specific consultation with Severn Trent Water will be critical to identify any risk of flooding from the public sewer (especially when a sewer passes through a site) and if the site is located in a reservoir flood zone.

8.1.4 Confirm that the development does not increase flood risk elsewhere.

Section 9 sets out these requirements for taking a sustainable approach to surface water management. Developers should also confirm that mitigation measures do not increase flood risk elsewhere and that floodplain compensation is provided where necessary.

While there are some water compatible developments which the NPPF indicates can be acceptable in functional floodplain (subject to the sequential and exception tests) these are discouraged).

All development must undertake an assessment on what flood risk betterment can be provided by the proposals. The assessment should include but not be limited to river restoration, enhancement including de-culverting, removing unnecessary structures and reinstating a natural, sinuous watercourse and creation of flood alleviation measures.

Where appropriate replacement dwellings should provide a flood risk betterment both on site and to third parties.

In catchments potentially at risk from cumulative effects of development, consideration should be given to locations known to be sensitive to changes in flood risk (these locations might be remote from application sites and could require measures assessed at a catchment scale).

8.1.5 Make the development safe for future users.

Consideration should first be given to minimising risk by planning sequentially across a site. Once risk has been minimised as far as possible, only then should mitigation measures be considered.

The PPG flood risk and coastal change guidance refers to the 'design flood' against which the suitability of a proposed development should be assessed and mitigation measures, if any, are designed. The 'design flood' is defined as the 1% AEP fluvial event or 1% AEP surface water event, plus an appropriate allowance for climate change. Allowances for climate change can be found in the [EA climate change guidance \(gov.uk\)](#).

Developers should consider both the actual and residual risk of flooding to the site, as discussed in Section 6.6. Further flood mitigation measures may be needed for any developments in an area protected by flood defences, where the condition of those defences is 'fair' or 'poor', and where the SoP is not of the required standard. Flood resistance and resilience measures should be considered to manage any residual flood risk by keeping water out of properties and seeking to reduce the damage caused, should water enter a property. Emergency plans should also account for residual risk, e.g., through the provision of flood warnings and a flood evacuation plans where appropriate.

Safe access and egress will need to be demonstrated during the design flood event. Access requirements are set out in the [PPG: Flood Risk and Coastal Change \(gov.uk\)](#) Paragraph: 047 Reference ID: 7-047-20220825.

8.1.6 Enhance the natural river corridor and floodplain environment through new development.

Developments should demonstrate opportunities to create, enhance, and link green assets. This can provide multiple benefits across several disciplines including flood risk and biodiversity/ecology and may provide opportunities to use the land for an amenity and recreational purposes. Development that may adversely affect green infrastructure assets should not be permitted. All development must undertake an assessment on what environmental betterment can be provided by the proposals. The assessment should include but not be limited to, river restoration, enhancement including de-culverting removing unnecessary structures and reinstating a natural, sinuous watercourse.

Biodiversity Net Gain (BNG) is a strategy to develop land and contribute to the recovery of nature. It is making sure the habitat for wildlife is in a better state than it was before development. BNG has been applicable since November 2023 for developments in the Town and Country Planning Act 1990, unless exempt, and has been applicable to small sites since April 2024. Further information is available on the Government BNG webpage, [here](#).

8.1.7 Consider and contribute to wider flood mitigation strategy and measures in the area and apply the relevant local planning policy.

Wherever possible, developments should seek to help reduce flood risk in the wider area, e.g., by contributing to a wider community scheme or strategy for strategic measures, such as defences or NFM or by contributing in-kind by mitigating wider flood risk on a development site. Developers must demonstrate in an FRA how they are contributing towards this vision. Further information and guidance on surface water management and SuDS is presented in Section 8.5.1.

Land that is required for current and future flood management will be safeguarded from development. Where development lies adjacent to or benefits from an existing or future flood defence scheme, the developer will be expected to contribute towards the cost of delivery and/or maintenance of the scheme.

8.2 Requirements for site-specific Flood Risk Assessments

8.2.1 When is an FRA required?

Site-specific FRAs are required for all development (including minor development and changes of use) in the following circumstances:

- Proposals on sites of one hectare or greater in Flood Zone 1.
- Proposals in Flood Zones 2 and 3.
- Proposals in an area within Flood Zone 1 which has critical drainage problems (as notified to the LPA by the EA) (see Section 9.4.4 for more information on critical drainage problems).
- Land identified in this SFRA as being at increased flood risk in the future.
- Proposed development or a change of use to a more vulnerable class subject to sources of flooding other than rivers (e.g. surface water).
- Proposals of less than one hectare in Flood Zone 1 where they could be affected by sources of flooding other than rivers (e.g. surface water)

8.2.2 Objectives of a site-specific FRA

Site-specific FRAs should be proportionate to the degree of flood risk and the scale, nature, and location of the development. Site-specific FRAs should establish:

- Whether a proposed development is likely to be affected by current or future flooding from any source.
- Reasonable opportunities to reduce flood risk
- Whether a proposed development will increase flood risk elsewhere.
- Whether the measures proposed to deal with the effects and risks are appropriate.
- The evidence, if necessary, for the LPA to apply the sequential test; and
- Whether, if applicable, the development will be safe and pass the exception test.

FRAs should follow the approach recommended by the NPPF (and associated guidance) and guidance provided by the EA, and SCC. Guidance and advice for developers on the preparation of site-specific FRAs is available from the following websites with hyperlinks provided:

- [Standing Advice on Flood Risk \(gov.uk\)](#)
- [Flood Risk Assessment for Planning Applications \(gov.uk\)](#); and
- [Site-specific Flood Risk Assessment: Checklist \(gov.uk\)](#)

Defra published [National flood risk standing advice for local planning authorities \(gov.uk\)](#) in 2015, providing guidance for LPAs for reviewing FRAs submitted as part of planning applications.

Guidance should be sought from the EA and the Council at the earliest possible stage, and opportunities should be taken to incorporate environmental enhancements and reduce flooding from all sources both to and from the site through development proposals.

Developers should seek to go beyond managing the flood risk and support reduction of wider flood risk, whilst enhancing and conserving the natural environment. Further advice can be found at: [Flood risk and coastal change - GOV.UK \(www.gov.uk\)](https://www.gov.uk/government/topics/floods-flood-preparation-and-protection).

8.2.3 Site layout and design

Flood risk should be considered at an early stage in deciding the layout and design of a site to provide an opportunity to reduce flood risk within the development. Developers should undertake early engagement with the EA, SCC as LLFA, and Severn Trent Water.

The NPPF states that a sequential, risk-based approach should be applied to try to locate more vulnerable land uses away from Flood Zones to higher ground and lower flood risk areas, while more flood-compatible development (e.g., vehicular parking, recreational space) can be located in higher risk areas. Higher risk areas can also be retained and enhanced as natural green space. Whether parking in floodplains is appropriate will be based on the likely flood depths and hazard, evacuation procedures and availability of flood warning.

Waterside areas, or areas along known flow routes, can act as green infrastructure, being used for recreation, amenity, and environmental purposes, allowing the preservation of flow routes and flood storage, and at the same time providing valuable social and environmental benefits contributing to other sustainability objectives. Landscaping should provide safe access to higher ground from these areas and avoid the creation of isolated islands as water levels rise.

When designing sites, developers should consider the hierarchy of drainage options, as stated in the PPG, aiming to discharge surface water runoff as high up the hierarchy as reasonably practicable:

1. into the ground (infiltration)
2. to a surface water body
3. to a surface water sewer, highway drain, or another drainage system
4. to a combined sewer

8.2.4 Modification of ground levels

Any proposal for modification of ground levels will need to be assessed as part of a detailed FRA. Modifying ground levels to raise the land above the required flood level is an effective way of reducing flood risk to a particular site in circumstances where the land does not act as conveyance for flood waters. However, care must be taken as raising land above the floodplain could reduce conveyance or flood storage in the floodplain and could adversely impact flood risk downstream or on neighbouring land. Raising ground levels can also deflect flood flows, so analyses should be performed to demonstrate that there are no adverse effects on third party land or property.

Compensatory flood storage should be provided, and would normally be on a level for level, volume for volume basis on land that does not currently flood but is adjacent to the floodplain (for it to fill and drain). It should be in the vicinity of the site and within the red line

of the planning application boundary (unless the site is strategically allocated).

[Appendix A3 of the CIRIA Publication C624 \(ciria.org\)](#) provides guidance on how to address floodplain compensation.

The EA would not normally consider, and would not support, stilted development or void space under buildings as a means of flood storage compensation. Stilts are a method of flood resistant construction and are not generally accepted as a means of allowing new development in unsuitable locations or over-development of brownfield sites.

Where proposed development results in a change in building footprint, the developer should confirm that it does not impact upon the ability of the floodplain to store or convey water and seek opportunities to provide floodplain betterment.

Raising levels can also create areas where surface water might pond during significant rainfall events. Any proposals to raise ground levels should be tested to check that it would not cause increased ponding or build-up of surface runoff on third party land. Consideration should be given to the impact of raising ground levels on adjacent properties, particularly the impact of raising ground levels on surface water runoff from a site, with potential to increase surface water flood risk.

Applicants should note that changes to manhole cover levels on public sewer and increase / displace flood risk which will require careful consideration with Severn Trent Water.

Applicants should not assume that any alteration to a public sewer, including diversion, will be acceptable as this could have adverse flood risk consequences.

For all developments regardless of any identified sewer flood risk that is identified on or near to the site, it is good practice for the finished floor levels and manhole cover levels (including those that serve private drainage runs) to be higher than the manhole cover level at the point of connection to the receiving sewer. Where the ground level of the site is below the ground level at the point where the drainage connects to the public sewer, care must be taken to ensure that the proposed development is not at increased risk of sewer surcharge.

8.2.5 Raised floor levels

If raised floor levels are proposed, these should be agreed with the Council and the EA. The minimum Finished Floor Level (FFL) may change dependent upon the vulnerability and flood risk to the development.

Developers should refer to the [Preparing a flood risk assessment: standing advice \(gov.uk\)](#) for the latest guidance on FFLs but generally the EA advises the minimum finished floor levels should be set 600mm above the 1% AEP fluvial plus climate change peak flood level, here the appropriate climate change allowances have been used (see Section 5.2). An additional allowance may be required because of risks relating to blockages to the channel, culvert or bridge and should be considered as part of an FRA. Lowering existing FFLs below the existing levels within the 1% AEP plus climate change floodplain would not be acceptable and should be discouraged. New development offers opportunities to improve the resilience of buildings

Allocating the ground floor of a building for less vulnerable, non-residential, use is an effective way of raising living space above flood levels. Single storey buildings such as ground floor flats or bungalows are especially vulnerable to rapid rise of water (such as that experienced during a breach). This risk can be reduced by use of multiple storey construction and raised areas that provide an escape route.

Similarly, the use of basements should be avoided. Habitable uses of basements within Flood Zone 3 and areas at risk of surface water flooding in the surface water flood zone B should not be permitted, whilst basement dwellings in Flood Zone 2 will be required to pass the exception test.

Where the ground level of a site is below the ground level at the point where the drainage connects to the public sewer, care must be taken to ensure that the proposed development is not at an increased risk of sewer surcharge. It is good practice for the finished floor levels and manhole cover levels (including those that serve private drainage runs) to be higher than the manhole cover level at the point of connection to the receiving sewer.

Alternatively, mitigation measures may need to be incorporated into the proposals to protect against sewer surcharge.

8.2.6 Development and raised defences

Construction of localised raised floodwalls or embankments to protect new development is not a preferred option, as a residual risk of flooding will remain. Compensatory storage must be provided where raised defences remove storage from the floodplain.

Where development is located behind, or in an area benefitting from defences, the residual risk of flooding must be considered.

8.2.7 Developer contributions

In some cases, and following the application of the sequential test, it may be appropriate for the developer to contribute to the improvement of flood defence provision that would benefit both proposed new development and the existing local community. Developer contributions can also be made to maintenance and provision of flood risk management assets, flood warning (or related infrastructure) and the reduction of surface water flooding (i.e., SuDS). This relates to the Community Infrastructure Levy, a charge that can be levied by local authorities on new development in their area to help them deliver the infrastructure needed to support development in their area, and planning obligations including Section 106. The government website provides further information on the [Community Infrastructure Levy \(gov.uk\)](https://www.gov.uk/guidance/community-infrastructure-levy) and [planning obligations \(gov.uk\)](https://www.gov.uk/guidance/planning-obligations).

8.2.8 Buffer strips

The provision of a buffer strip to allows additional capacity to accommodate climate change and means access to the watercourse, structures and defences is maintained for future maintenance purposes. It also enables the avoidance of disturbing riverbanks, adversely impacting ecology, and having to construct engineered riverbank protection. Any

watercourse crossings should ensure that flood risk is not impacted. A buffer strip of at least 8m but ideally larger is required from any main river. Where flood defences are present, these distances should be taken from the toe of the defence.

Building adjacent to riverbanks can cause problems to the structural integrity of the riverbanks and the building itself, making future maintenance of the river much more difficult. [Flood Risk Activity Permits \(gov.uk\)](#) from the EA are likely to be required for development in these areas alongside any permission. There should be no built development within these distances from main rivers / flood defences (where present).

8.2.9 Making space for water

The PPG sets out a clear aim in Flood Zone 3 to create space for flooding by restoring functional floodplain. Generally, development should be directed away from these areas.

All new development close to rivers should consider the opportunity to improve and enhance the river environment. Developments should look at opportunities for river restoration and enhancement as part of the development. Options include backwater creation, de-silting, in-channel habitat enhancement and removal of structures. When designed properly, such measures can have benefits such as reducing the costs of maintaining hard engineering structures, reducing flood risk, improving water quality, and increasing biodiversity. Social benefits are also gained by increasing green space and access to the river.

8.3 Resistance and resilience measures

Resistance measures aim to reduce the amount of floodwater entering the building and resilience measures aim to reduce the damage caused by flood water which has entered the property.

The consideration of resistance and resilience measures should not be used to justify development in inappropriate locations. However, having applied planning policy there may be some instances where development is permitted in high flood risk areas. In these cases, the above measures should be considered before resistance and resilience measures are relied on.

There may also be opportunities for 'change of use' developments to be used to improve the flood resistance and resilience of existing development, which may not have been informed by a site-specific flood risk assessment when it was first constructed.

Further information and guidance on best practice can be found in the following locations:

- Department for Communities and Local Government [Improving the Flood Performance of New Buildings: Flood Resilient Construction \(gov.uk\)](#)
- [CIRIA Property Flood Resilience Code of Practice \(ciria.org\)](#)
- [EA Flood resilience construction of new buildings \(gov.uk\)](#)

8.3.1 Resistance measures

Most of the resistance measures should be regarded as reducing the rate at which flood water can enter a property during an event and considered an improvement on what could be achieved with sandbags. They are often deployed with small scale pumping equipment to control the flood water that does seep through these systems. The effectiveness of these forms of measures is often dependant on the availability of a reliable forecasting and warning system, so the measures are deployed in advance of an event. The following resistance measures are often deployed:

- **Permanent barriers:** can include built up doorsteps, rendered brick walls, and toughened glass barriers.
- **Temporary barriers:** which consist of moveable flood defences which can be fitted into doorways and/or windows. On a smaller scale, temporary snap on covers for airbricks and air vents can also be fitted to prevent the entrance of flood water.
- **Community resistance measures:** these include demountable defences that can be deployed by local communities to reduce the risk of water ingress to several properties. The methods require the deployment of inflatable (usually with water) or temporary quick assembly barriers in conjunction with pumps to collect water that seeps through the systems during a flood.

8.3.2 Resilience measures

Flood resilience measures aim to limit any permanent damage, prevent the structural integrity of the building being compromised and make the clean up after the flood easier. Interior design measures to reduce damage caused by flooding can include electrical circuitry installed at a higher level and water-resistant materials for floors, walls, and fixtures.

8.4 Reducing flood risk from other sources

8.4.1 Groundwater

Groundwater flooding has a very different flood mechanism to any other and so many conventional flood mitigation methods are not suitable. The only way to fully reduce flood risk would be through building design (development form), ensuring floor levels are raised above the water levels caused by a 1% AEP plus climate change event. Site design would also need to preserve any flow routes followed by the groundwater overland so that flood risk is not increased downstream.

Infiltration SuDS can cause increased groundwater levels and subsequently may increase flood risk on or off a site. Developers should provide evidence that this will not be a significant risk. Other underground works, such as basements, may also need to be assessed as part of a site-specific FRA in certain prone areas susceptible to groundwater issues.

8.4.2 Surface water and sewer flooding

Developers should discuss public sewerage capacity with the water utility company at the earliest possible stage. It is important that a Surface Water Drainage Strategy (often undertaken as part of an FRA) shows that this will not increase flood risk elsewhere, and that the drainage requirements regarding runoff volumes and rates and SuDS for new development are met.

If residual surface water flood risk remains, the likely flow routes and depths across the site should be modelled. The site should be designed so that these flow routes are preserved and building design should provide resilience against this residual risk.

When redeveloping existing buildings, the installation of some permanent or temporary floodproofing and resilience measures could protect against both surface water and sewer flooding. Non-return valves prevent water entering the property from drains and sewers. Non-return valves can be installed within gravity sewers or drains within a property's private sewer upstream of the public sewerage system. These need to be carefully installed and must be regularly maintained.

Consideration must also be given to attenuation and flow ensuring that flows during the 1% AEP plus climate change storm event are retained within the site if any flap valves shut. This should be demonstrated with suitable modelling techniques. As noted above, early consultation with Severn Trent Water will be critical to understand sewer flood risk especially when a sewer passes through a site. Where an existing sewer flood risk affects a site, applicants will need to carefully consider how this can be managed with Severn Trent Water. Sewer flood risk could affect the developable area and the detailed design of the site.

8.4.3 Reservoirs

As discussed in Section 4.8, the risk of reservoir flooding is extremely low. However, there remains a residual risk to development from reservoirs which developers should consider during the planning stage.

Developers should contact the reservoir owner for information on:

- the Reservoir Risk Designation
- reservoir characteristics: type, dam height at outlet, area/volume, overflow location
- operation: discharge rates / maximum discharge
- discharge during emergency drawdown; and
- inspection / maintenance regime.

Developers should use the above information to:

- Apply the sequential approach to locating development within the site.
- Consider the impact of a breach and overtopping, particularly for sites proposed to be located immediately downstream of a reservoir. This should consider

whether there is sufficient time to respond, and whether in fact it is appropriate to place development immediately on the downstream side of a reservoir.

- Assess the potential hydraulic forces imposed by sudden reservoir failure event and check that the proposed infrastructure fabric could withstand the structural loads.
- Develop site-specific Emergency Plans and/ or Off-site Plans if necessary and make the future users of the development aware of these plans. This may need to consider emergency drawdown and the movement of people beforehand.

It should also be understood that the “risk category” of a reservoir is set by the potential damage and loss of life in circumstances where there is a breach or an extreme flood event. Accordingly, it is possible that allocation of new development downstream of an existing reservoir could potentially change the risk category and result in a legal requirement (under the Reservoirs Act 1975) to improve the structural and hydraulic capacity of the dam. As the cost of implementing such works can be substantial consideration should be given to considering the implications and whether it would be more appropriate to place development in alternative locations not associated with such risk.

8.5 Emergency planning

The Civil Contingencies Act 2004 lists Local Authorities, the Environment Agency and emergency services as Category 1 responders, responsible for reducing, controlling, and mitigating the effects of emergencies in both response and recovery phases.

The 2023 NPPF (Paragraph 173) requires site-level FRAs to demonstrate that “any residual risk can be safely managed; and safe access and escape routes are included where appropriate, as part of an agreed emergency plan.”

In accordance with the NPPF, SFRAs, PFRAs and SWMPs can be used in the preparation and execution of a flood emergency plan as they can indicate areas that may be at risk of flooding. These can be provided as part of an FRA or as a separate document. Decisions regarding whether an Emergency Plan is required sits with the LPA, with advice from their Emergency Planning Teams, the Environment Agency and LLFA.

According to the PPG flood risk and coastal change guidance, an emergency plan is needed wherever emergency flood response is an important component of making a development safe; this includes the free movement of people during a ‘design flood’ and potential evacuation during an extreme flood.

Emergency plans are essential for any site with transient occupancy in areas at risk of flooding, such as holiday accommodation, hotels, caravan, and camping sites (PPG: Flood risk and coastal change paragraph 043).

Emergency Plans should consider:

- The type of flood risk present, and the extent to which advance warning can be given in a flood event.
- The number of people that would require evacuation from the area potentially at risk.

- The vulnerability of site occupants.
- The impact of the flooding on essential services e.g., electricity, gas, telecommunications, water supply and sewerage.
- Safe access and egress for users and emergency services.

Further information is available from the following documents / websites with hyperlinks provided:

- [The National Planning Policy Guidance \(gov.uk\)](#)
- [2004 Civil Contingencies Act \(legislation.gov.uk\)](#)
- [Defra \(2014\) National Flood Emergency Framework for England \(gov.uk\)](#)
- [FloodRe \(floodre.co.uk\)](#)
- The EA and Defra's [Standing Advice for FRAs \(gov.uk\)](#)
- [TBC 'Flooding' page](#)
- EA's ['How to plan ahead for flooding' \(gov.uk\)](#)
- [Sign up for Flood Warnings with the EA \(gov.uk\)](#)
- [The National Flood Forum \(nationalfloodforum.org.uk\)](#)
- ['Prepare for flooding' \(gov.uk\)](#)
- [ADEPT Flood Risk Plans for new development \(adeptnet.org.uk\)](#)
- [Staffordshire County Council- 'Flooding and drainage' page](#)

8.5.1 Local Resilience Forum

Local Resilience Forums (LRFs) are multi-agency partnerships made up of representatives from local public services, including the emergency services, local authorities, the NHS, the Environment Agency, and others (Category 1 Responders). LRFs are supported by organisations, known as Category 2 responders, such as the Highways Agency and public utility companies.

Staffordshire Prepared is the Local Resilience Forum which provides information and advice on how residents, businesses, and communities together can prepare for, respond to, and recover from emergencies. Further information is available on the [Staffordshire Prepared](#) website.

The Government website provides contact details for all local resilience forums across the UK.

9 Surface water management and SuDS

This section provides guidance and advice on managing surface water runoff and flooding.

9.1 Roles of the Lead Local Flood Authority and Local Planning Authority in surface water management

Staffordshire County Council (SCC), as the LLFA, are a statutory planning consultee. They provide technical advice on surface water drainage strategies and designs put forward for major development proposals, to confirm that onsite drainage systems are designed in accordance with the current legislation and guidance.

When considering planning applications, the drainage/flood risk engineering team will provide advice to the Planning Department on the management of surface water. The LPA should satisfy themselves that the development's proposed minimum standards of operation are appropriate and, using planning conditions or planning obligations, that there are clear arrangements for on-going maintenance over the lifetime of the development.

It is essential that developers consider sustainable drainage at an early stage of the development process – ideally at the pre-application or master-planning stage. To further inform development proposals at the master-planning stage, pre-application submissions are accepted by the Council. This will assist with the delivery of well designed, appropriate, and effective SuDS. Applicants are also encouraged to engage with Severn Trent Water to discuss their surface water proposals, especially where adoption is proposed.

Currently the implementation of SuDS is driven through planning policy. Schedule 3 of the FWMA 2010 will provide a framework for the approval and adoption of drainage systems, a SuDS Approving Body (SAB) within unitary and county councils, and national standards on the design, construction, operation, and maintenance of SuDS for the lifetime of the development. Timescales for enactment of Schedule 3 by the Government are unknown.

9.2 Sustainable Drainage Systems (SuDS)

SuDS are designed to maximise the opportunities and benefits that can be secured from surface water management practices.

SuDS provide a means of dealing with the quantity and quality of surface water and can also provide amenity and biodiversity benefits. Given the flexible nature of SuDS, they can be used in most situations within new developments as well as being retrofitted into existing developments. SuDS can also be designed to fit into most spaces, for example, permeable paving could be used in parking spaces or rainwater gardens as part of traffic calming measures.

It is a requirement for all major development proposals that SuDS for management of runoff are put in place, unless there is clear evidence that this would be inappropriate (NPPF Paragraph 175). Where possible, SuDS that offer multiple benefits should be given priority.

It is important that SuDS are maintained for the lifetime for the development so that features can function as designed. Consideration should be given to enhancing SuDS to achieve biodiversity net gain.

SuDS should not be used individually but as a series of features in an interconnected system designed to capture water at the source and convey it to a discharge location. Collectively this concept is described as a SuDS Management Train (see Figure 9-1).

The number of treatment stages required within the Management Train depends primarily on the source of the runoff and the sensitivity of the receiving waterbody or groundwater.




Figure 9-1: SuDS Management Train.

9.3 Sources of SuDS guidance

9.3.1 C753 CIRIA SuDS Manual (2015)

[The C753 CIRIA SuDS Manual \(2015\) \(ciria.sharefile.com\)](http://ciria.sharefile.com) provides guidance on planning, design, construction, and maintenance of SuDS. The manual is divided into five sections ranging from a high-level overview of SuDS, progressing to more detailed guidance with progression through the document.

9.3.2 Non-Statutory Technical Guidance, Defra (March 2015)

Non-Statutory Technical Standards for SuDS (gov.uk) provides non-statutory standards on the design and performance of SuDS. It outlines peak flow control, volume control, structural integrity, flood risk management and maintenance and construction considerations.

9.3.3 Non-statutory Technical Guidance for Sustainable Drainage Practice Guidance, LASOO (2016)

The Local Authority SuDS Officer Organisation (LASOO) produced their Practice Guidance (susdrain.org) in 2016 to give further detail to the Non-Statutory technical guidance.

9.3.4 Water Industry Design and Construction Guidance

The Design and Construction Guidance (DCG) (water.org.uk), part of a new Codes for Adoption covering the adoption of new water and wastewater infrastructure by water companies, contains details of the water sector's approach to the adoption of SuDS.

9.3.5 Local Authority SuDS Guidance

The 2024 NPPF states that flood risk should be managed "using opportunities provided by new development and improvements in green and other infrastructure to reduce the causes and impacts of flooding" (NPPF Paragraph 167).

SCC's Surface water drainage for developments (Information for Planners and Developers - Staffordshire County Council) webpage is dedicated to information regarding SuDS. This includes a summary of what SuDS are and planning application requirements.

The SuDS Handbook, sets out the role of SuDS in achieving sustainable development across nine Lead Local Authorities in the West Midlands, including Staffordshire County Council (SCC). This shows how early consideration of surface water drainage issues can ensure that an effective SuDS scheme can be delivered on any site.

9.4 Other surface water considerations

9.4.1 Groundwater Vulnerability Zones

The EA published new groundwater vulnerability maps in 2015. These maps provide a separate assessment of the vulnerability of groundwater in overlying superficial rocks and those that comprise of the underlying bedrock. The map shows the vulnerability of groundwater at a location based on the hydrological, hydro-ecological, and soil properties within a one-kilometre grid square.

The groundwater vulnerability maps should be considered when designing SuDS. Depending on the height of the water table at the location of the proposed development site, restrictions may be placed on the types of SuDS appropriate to certain areas. Groundwater vulnerability maps can be found on Defra's interactive mapping (defra.gov.uk).

9.4.2 Groundwater Source Protection Zones (GSPZ)

The EA also defines Groundwater Source Protection Zones (GSPZs) near groundwater abstraction points. These protect areas of groundwater used for drinking water. The GSPZ requires attenuated storage of runoff to prevent infiltration and contamination. GSPZs can be viewed on [Defra's interactive mapping \(defra.gov.uk\)](https://defra.gov.uk). Three main zones are defined as follows:

- Inner protection zone (Zone 1) - areas from where pollution can travel to the groundwater source within 50 days or is at least a 50m radius.
- Outer protection zone (Zone 2) - areas from where pollution can travel to the groundwater source within 400 days or lies within the nearest 25% of the total catchment area (whichever is largest).
- Total catchment (Zone 3) - the total area needed to support removal/discharge of water from the groundwater source.

Online mapping shows there are no GSPZs within Tamworth borough. However, one is located along the northwestern border of the borough, but this does not encroach the borough boundary.

9.4.3 Nitrate Vulnerable Zones

Nitrate Vulnerable Zones (NVZs) are areas designated as being at risk from agricultural nitrate pollution. Nitrate levels in waterbodies are affected by surface water runoff from surrounding agricultural land entering receiving waterbodies. The level of nitrate contamination will potentially influence the choice of SuDS and should be assessed as part of the design process.

NVZs can be viewed on the [EA's interactive mapping \(data.gov.uk\)](https://data.gov.uk). There is one pre appeal NVZ 2021 to 2024 area affecting the borough:

- Surface Water S308 - River Trent (source to confluence with Derwent) NVZ

Currently, information on the 2021 to 2024 NVZs post-appeal is unavailable. Landowners can appeal an NVZ designation once notified if their land (or part of it):

- Does not drain into water that has been identified as polluted.
- Drains into water that should not be identified as polluted.

9.4.4 Critical Drainage Areas

Areas with Critical Drainage Problems (ACDPs) is land formally notified to the LPA by the EA as having critical drainage problems. Within ACDPs, proposed development may present increased risks of flooding both on and off site if the surface water runoff is not effectively managed. A dataset containing ACDPs is available to download from the EA website [here](#). There are currently no ACDPs identified within the study area.

Local Authorities can also choose to designate Critical Drainage Areas (CDAs) within their authority area; however, there are no CDAs currently designated within the borough.

10 Recommendations

10.1 Borough-wide recommendations

10.1.1 Sequential and exception tests

The SFRA has identified that parts of the study area are at high risk of flooding. With a view to the allocated sites across the borough, we have provided information for the Council to apply the sequential test.

The Council should use the information in this SFRA when deciding which development sites to take forward in their LPU. It is the responsibility of the Council to be satisfied that the sequential test has been fulfilled. Once potential sites are identified, consultation with Severn Trent Water will be required to identify any sewer flood risk.

10.1.2 Sequential approach to development

The NPPF supports a risk-based and sequential approach to development and flood risk in England, so that development is located in the lowest flood risk areas where possible; it is recommended that this approach is adopted for all future developments within the study area.

New development and re-development of land should wherever possible seek opportunities to reduce overall level of flood risk at the site, for example through the following:

- A sequential approach to site design should be used to reduce risk.
- Re-development within areas of flood risk which provide other wider sustainability benefits should also provide flood risk betterment and be made resilient to flooding.
- Long-term opportunities to remove development from the floodplain and to make space for water should be identified.
- Ordinary watercourses not currently afforded flood maps should be modelled to an appropriate level of detail to enable a sequential approach to the layout of the development.
- Opportunities should be identified for brownfield sites in functional floodplain to reduce risk and provide flood risk betterment.
- Opportunities should be identified to help fund future flood risk management through developer contributions to reduce risk for surrounding areas.
- Opportunities to make space for water to accommodate climate change should be sought.

10.1.3 Site-specific Flood Risk Assessments

Site-specific FRAs are required to be produced by developers to provide a greater level of detail on flood risk and any protection provided by defences and, where necessary, demonstrate the development passes part b of the Exception Test. Site-specific FRAs should be undertaken in-line with the [EA's FRA Standing Advice \(gov.uk\)](https://www.gov.uk/government/uploads/system/uploads/attachment_data/file/444444/EA-FRA-Standing-Advice.pdf).

Developers should consult with the Council, SCC as LLFA, the EA, and Severn Trent Water at an early stage to discuss flood risk including requirements for site-specific FRAs, detailed hydraulic modelling, and drainage assessment and design.

10.1.4 Drainage strategies and SuDS

Planners should be aware of the conditions set by the LLFA for surface water management. The future enactment of Schedule 3 of the FWMA means that there will be mandatory standards for delivery and adoption of SuDS in new developments; however, this has not yet been enacted.

Space should be provided for the inclusion of SuDS on all allocated sites, outline proposals and full planning applications. SuDS design should demonstrate how constraints have been considered and how the design provides multiple benefits e.g. landscape enhancement, biodiversity, recreation, amenity, leisure, and the enhancement of historical features.

SuDS must be designed appropriately for the area. Large parts of Tamworth Borough are underlain by mudstone geology; therefore, infiltration SuDS may not be appropriate in these areas. Infiltration testing must be undertaken to determine whether infiltration rates are suitable for the use of infiltration SuDS. Where sites lie within or close to groundwater source protection zones (GSPZs) or aquifers, there may be restrictions on infiltration SuDS and guidance should be sought from the LLFA and the EA.

Planning applications for phased developments should be accompanied by a drainage strategy, which takes a strategic approach to drainage provision across the entire site and incorporates adequate provision for SuDS within each phase. Applicants will need to demonstrate a holistic and co-ordinated approach to both foul and surface water drainage and the management of flood risk.

SuDS should be designed based on the SuDS management train to prevent and control pollutants to prevent the 'first flush' polluting the receiving waterbody.

SuDS should be designed so that they are easy to maintain, and it should be set out who will maintain the system, how the maintenance will be funded and should be supported by an appropriately detailed maintenance and operation manual.

10.1.5 Residual risk

Residual risk is the risk that remains after mitigation measures are considered. All residual risks to a site should be considered during the planning stage as part of site-specific FRAs.

There are limited flood defences in the borough, however, any development in areas protected by these flood defences should consider the residual risk of overtopping or breach of these defences.

Other residual risks that may be applicable to development sites within the borough include potential breaches or overtopping of the reservoirs, and blockages or failure of infrastructure, such as culverts.

10.1.6 Safe access and egress

Safe access and egress will need to be demonstrated at all development sites.

If raised access routes are required, an assessment must be made to check this will not displace floodwater elsewhere.

Emergency vehicular access should be possible during times of flood. If at risk, then an assessment should be made to detail the flood duration, depth, velocity, and flood hazard rating in the 1% AEP plus climate change flood event, in line with FD2320.

Where development is located behind, or in an area benefitting from defences, consideration should be given to the potential safety of the development, FFLs and for safe access and egress in the event of rapid inundation of water due to a defence breach with little warning.

10.1.7 River restoration and habitat improvement

Developments should be used as an opportunity to enhance the existing river corridor. Natural drainage features should be maintained, and opportunities identified for river restoration/enhancement to make space for water.

Opportunities should be identified to maintain and enhance permeable surfaces and greenspaces to help reduce surface water runoff whilst promoting other benefits, including biodiversity and wellbeing.

There should be no built development within 8m from the top of a watercourse or main river for the preservation of the watercourse corridor, wildlife habitat, flood flow conveyance and future watercourse maintenance or improvement.

Culverting of open watercourses should be avoided except where essential to allow highways and/or other infrastructure to cross, in line with CIRIA's Culvert design and operation guide (C689) and to restrict development over culverts.

[Countryside Stewardship schemes \(gov.uk\)](https://www.gov.uk/countryside-stewardship-schemes) should be promoted to help prevent soil loss and reduce runoff from agricultural land whilst also providing biodiversity and habitat improvements.

10.1.8 Emergency planning and flood awareness

Improved emergency planning and flood awareness provide an opportunity to mitigate against flood risk. The following recommendations should be considered:

- The Council should work with emergency planning colleagues through the Resilience Partnership Team to identify areas at highest risk and locate most vulnerable receptors. For major developments, robust emergency (evacuation) plans should be produced and implemented.
- Increased flood awareness and sign-up to the [EA Flood Warnings \(gov.uk\)](https://www.gov.uk/eas) should be promoted across the borough.
- Exceedance flows, both within and outside of the site, should be appropriately designed to minimise risks to both people and property.

10.2 Recommendations from the CIA

The CIA (see Section 7 and Appendix F) sets out a number of broadscale recommendations to mitigate the potential cumulative impact of development on flood risk across the borough, and specific recommendations for those catchments identified to be at high or medium sensitivity to increased flood risk.

10.2.1 Broadscale recommendations

The following policy recommendations apply to all catchments within the study area:

- Tamworth Borough Council should work closely with neighbouring local authorities to develop complementary Local Planning Policies for catchments that drain into and out of the area to other local authorities in order to minimise any cross-boundary issues of cumulative impacts of development.
- Developers should incorporate SuDS and provide details of adoption, ongoing maintenance, and management on all development sites. Proposals will be required to provide reasoned justification for not using SuDS techniques, where ground conditions and other key factors show them to be technically feasible. Preference will be given to systems that contribute to the conservation and enhancement of biodiversity and green infrastructure where practicable. Developers should refer to the relevant Lead Local Flood Authority (LLFA) guidance for the requirements for SuDS in Tamworth Borough. Further guidance on SuDS can be found in Section 9 of the main report.
- Staffordshire County Council as LLFA will review Surface Water Drainage Strategies in accordance with their local requirements for major and non-major developments. These should consider all sources of flooding to ensure that future development is resilient to flood risk and does not increase flood risk elsewhere.
- Where appropriate, the opportunity for NFM in rural areas, SuDS retrofit in urban areas and river restoration should be maximised. Culverting should not be supported, and day-lighting existing culverts should be promoted through new developments.
- Runoff rates from all development sites must be limited to greenfield rates (including brownfield sites) unless it can be demonstrated that this is not practicable. If it is demonstrated that greenfield rates are not practicable then the

runoff rates should be restricted to the closest rate that is practicable but not exceeding the existing brownfield runoff rate.

- Where required, site-specific FRAs should explore opportunities to provide wider community flood risk benefits through new developments. Measures that can be put in place to contribute to a reduction in flood risk downstream should be considered. This may be either by the provision of additional storage on site e.g. through oversized SuDS, NFM techniques, green infrastructure, and green-blue corridors, and/ or by providing a Partnership Funding contribution towards any flood alleviation schemes.
- Tamworth Borough Council should consider requiring developers to contribute to community flood defences outside of their red line boundary to provide wider benefits and help offset the cumulative impact of development.

10.2.2 Recommendations for higher risk catchments

The following recommendations are made for high and medium risk catchments:

- Developers should include a construction surface water management plan to support the Construction Drainage Phasing Plan. This should provide information to the EA, the LLFA and the Local Planning Authority (LPA) regarding the proposed approach to surface water management in storm events during the construction phase.
- The LLFA and LPA should consult with Local Not-For-Profit organisations such as wildlife trusts, rivers trusts, and catchment partnerships. This will help to understand ongoing and upcoming projects where NFM, flood storage and attenuation, and environmental betterment may be possible alongside developments and aid in reducing flood risk.
- The LPA should work closely with the EA and the LLFA to identify any areas of land that should be safeguarded for any future flood alleviation schemes and NFM features. The EA Working with Natural Processes (WWNP) mapping can help identify where NFM features may be suitable (see Section 7.4 for further details). Investigations should seek to determine where developments have the potential to contribute towards works to reduce flood risk and enable regeneration in catchments as well as contributing to the wider provision of green infrastructure.
- Use of oversized SuDS should be considered, where viable, to provide betterment beyond the existing greenfield runoff rate.
- Opportunities for retrofitting of SuDS in existing developed areas should be sought to reduce runoff rates from existing developments.

Specific recommendations are made for each of the high-risk catchments below:

- **River Tame from River Anker to River Trent:** Many greenfield and brownfield sites have been identified in TBC's SHLAA in this catchment which, if developed, could utilise NFM and oversized SuDS techniques to reduce surface water flows causing local flooding issues and channelling water into the River Tame. As

Tamworth intersects the most upstream end of this catchment, techniques implemented here have potential to benefit Lichfield District downstream. It is worth noting that the other catchments assessed in the CIA are located immediately upstream of this catchment, therefore consideration must be given to the impact of development in these upstream catchments on flood risk in this catchment.

- **River Tame from R Blythe to River Anker:** While little development has been identified in the area of this catchment upstream of Tamworth, techniques to reduce surface water runoff from sites identified in TBC's SHLAA within this catchment can also benefit the River Tame from River Anker to River Trent catchment downstream. Within this catchment, NFM opportunities could be explored where appropriate at sites such as Middleton Lakes and Tameside Nature Reserve.
- **River Anker from River Sence to River Tame:** There are multiple large development sites allocated in the North Warwickshire District located upstream of Tamworth within this catchment. TBC could work in partnership with North Warwickshire Council to identify any opportunities for NFM techniques and oversized SuDS in these upstream areas of the catchment to provide local benefit alongside downstream benefit in Tamworth. A large number of sites have been put forward in this catchment as part of TBC's SHLAA, therefore techniques such as oversized SuDS could be explored to reduce flood risk from the surface water flow paths that have been identified within the catchment. As the River Anker joins the River Tame at the downstream end of the catchment consideration should also be given to how interventions in this catchment influence flows in the River Tame downstream.

10.3 Requirements for a Level 2 SFRA

Following the application of the sequential test, where sites cannot be appropriately accommodated in low-risk areas, the Council will apply the NPPF's exception test. In these circumstances, a Level 2 SFRA may be required, to assess in more detail the nature and implications of the flood characteristics.

As part of this Level 1 SFRA, an initial site screening exercise using site boundaries and flood risk data has been undertaken for the Council to help inform the application of the sequential test and subsequent potential requirement for a Level 2 SFRA.

10.4 SFRA report recommendations

10.4.1 Updates to SFRA

SFRAs are high-level strategic documents and, as such, do not go into detail on an individual site-specific basis. This SFRA has been developed using the best available information, supplied at the time of preparation.

Over time, new information will become available to inform planning decisions. When using the SFRA to prepare FRAs it is important to check that the most up to date information is used.

The EA regularly reviews its hydrology, hydraulic modelling, and flood risk mapping, and it is important that they are approached to determine whether updated (more accurate) information is available prior to commencing a site-specific FRA.

The EA have produced new national flood risk mapping (NaFRA2) which was made available in early 2025. There are planned future updates through 2025 and 2026.

Developers should check the online [Flood Map for Planning \(gov.uk\)](https://www.gov.uk/flood-map-for-planning) in the first instance to identify any major changes to the Flood Zones and the long-term flood risk mapping portal for any changes to flood risk from surface water or inundation from reservoirs.

Other datasets used to inform this SFRA may also be updated periodically and following the publication of this SFRA, new information on flood risk may be provided by RMAs.

Appendices

A GeoPDF Mapping and User Guide

B Data Sources used in this SFRA

C SFRA User Guide: Sequential test methodology

D Summary of flood risk across the borough

Offices at

Bristol
Coleshill
Doncaster
Dublin
Edinburgh
Exeter
Glasgow
Haywards Heath
Isle of Man
Leeds
Limerick
Newcastle upon Tyne
Newport
Peterborough
Portsmouth
Saltair
Skipton
Tadcaster
Thirsk
Wallingford
Warrington

Registered Office
1 Broughton Park
Old Lane North
Broughton
SKIPTON
North Yorkshire
BD23 3FD
United Kingdom

+44(0)1756 799919
info@jbaconsulting.com
www.jbaconsulting.com
Follow us:  

Jeremy Benn
Associates Limited
Registered in England
3246693

JBA Group Ltd is
certified to:
ISO 9001:2015
ISO 14001:2015
ISO 27001:2013
ISO 45001:2018